| Original | Replacement |
|---|---|
| Tv | TV/ Radio / |
| Power | Power |
| World | Smart / List |
| [ ≡] / Text | Text / Goto |
| Sleep | Sleep / Timer |
| Music/ Movie/ Phot | Sound / Title |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| Source/ Games | AV / Input / RDS |
| 0 | 0 |

| Original | Replacement |
|---|---|
| Recall | Shift + Back / Return |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |
| Blue | Blue / Prime Video / Random |
| Vol + | Vol + |
| Mute | Mute / Dimmer |
| PR+ | CH+ / Page+ |
| Vol - | Vol - |
| i | Info / Angle |
| PR- | CH- / Page- |
| Menu | Menu / Home |
| Up | Up |
| Q. Menu | D. Menu / Top |
| Left | Left |
| OK | OK |
| Right | Right |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| BACK | Back | RETURN BACK | Back / Return | | |
| | Down | | Down | | |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| | [ ≡] . . | OPT-TOOLS SETUP | Setup / OPT / | | |
| LANG | Lang | LANG I/II AUDIO | Audio / Lang I/II | | |
| | Q/ * | SIZE ZOOM | Zoom / Size | | |
| | Q. . / * | FORMAT PICTURE | Picture / Format | | |
| | Play | SLOW | Play / Slow | | |
| | Stop | HOLD | Stop / Hold | | |
| | << | TUNE- | << / Tune- | | |
| | >> | TUNE+ | >> / Tune+ | | |
| | Pause | STEP-FREEZE | Pause / Step / Freeze | | |
| | Rec | REC MODE | Rec / Rec Mode | | |
| | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| | [ - O- ] | MEDIA DISPLAY | Display / Media | | |
| | | | | | |
| | | | | | |