Original		Replacement		Original		Replacement	
	Input	RDS AV INPUT	AV / Input / RDS	ATV/ DTV	ATV/ DTV	PROGRAM TV/ RADIO	TV/ Radio /
	Power		Power		Vol +	VOL	Vol +
	[▼]	PC FAV MARKER	Fav / Marker / PC		[≡i]/[i+]	ANGLE INFO	Info / Angle
TEXT	Text	GOTO TEXT	Text / Goto	P	PR+	CH PAGE	CH+ / Page+
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		Vol -	VOL	Vol -
	O)/I/II	LANG I/II AUDIO	Audio / Lang I/II		Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1	P	PR-	CH PAGE	CH- / Page-
2	2	DVD 2	2	QUICK	Quick	LIST SMART	Smart / List
3	3	CD - STB 3	3	GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
4	4	VIDEO 4	4		Up		Up
5	5	TAPE 5	5	EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
6	6	TUNER 6	6		Left		Left
7	7	AUX - HDD 7	7	OK	OK	OK	OK
8	8	USB 8	8		Right		Right
9	9	BLUETOOTH 9	9	MENU	Menu	HOME MENU	Menu / Home
AD	AD	TITLE SOUND	Sound / Title		Down		Down
0	0	HDMI - SAT 0	0	RETURN	Return	RETURN BACK	Back / Return

Original	Replacement	Original	Replacement
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
[≡?]	Display / Media		
[≡+]	Stop / Hold		
[≡♦]	Zoom / Size		
Timer / [≡x]	Sleep / Timer		