Original		Replacement	
	Power		Power
	Red/ ↑	NETFLIX SEARCH	Red / Netflix / Search
	green/ ↓	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	[≡o]	TIMER SLEEP	Sleep / Timer
	[≡+]	HOLD	Stop / Hold
	[≡x]	LIST SMART	Smart / List
	[≡]	GOTO TEXT	Text / Goto
	[/≡]	OPT-TOOLS SETUP	Setup / OPT /
	[≡♦] / [+] / Wide	HOME MENU	Menu / Home
	[≡?]	SHIFT + ANGLE INFO	Shift + Info / Angle
	[≡i] / Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3

Original		Replacement	
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
SWAP P<P	P<P/ Swap	FORMAT PICTURE	Picture / Format
	0	HDMI-SAT 0	0
EXIT -/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
	Vol -	VOL −	Vol -
	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
	P-	CH PAGE −	CH- / Page-
	P+	+ CH PAGE	CH+ / Page+
	[i] / Info	ANGLE INFO	Info / Angle
TV/DTV	Tv/ DTV	PROGRAM TV/ RADIO	TV/ Radio /
SOURCE AV	[AV] / Source	RDS AV INPUT	AV / Input / RDS

Original	Replacement	Original	Replacement
I - II	Audio / Lang I/II		
PP	Back / Return		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
M	D. Menu / Top		
Down	Down		