Original		Replacement	
	Power		Power
	Power Tv	SHIFT +	Shift + Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
≥10	+10	EPG 1. -/--	-/-- / EPG
CANCEL	Cancel	WIDE	WIDE
INPUT AV	Tv/Av Tv	SHIFT + SRC	Shift + SRC
VOL +	Vol +Tv	SHIFT + ▶	Shift + RIGHT
VOL −	Vol -Tv	SHIFT + ◀	Shift + LEFT

Original		Replacement	
VOL +	Vol +	VOL +	VOL +
VOL	Vol -	VOL −	VOL -
MUTE	Mute		MUTE
DVD	Dvd	VOD	VOD
USB	Usb	MEDIA	MEDIA
EXT-IN RADIO	EXT-IN/RADIO	SRC	SRC
SEARCH ◀◀	<< Slow/Search	◀◀	Rewind
SEARCH ▶▶	>> Slow/Search	▶▶	Fast Forward
SKIP ⏮	I<<Skip	⏮	First
SKIP ⏭	>>I Skip	⏭	Last
▶PLAY	Play	▶	Play
PAUSE	Pause	⏸	Pause
STOP	Stop	■	Stop
FUNCTIONS	Functions	OPT+	OPT+
EXIT	Exit	EXIT	EXIT
TOP MENU	Top Menu	INFO	INFO
START	Start	FAV 2. P/C	P/C / FAV

Original		Replacement	
MENU	Menu	MENU	MENU
▲	Up	▲	UP
▼	Down	▼	DOWN
◀	◁ I / Left	◀	LEFT
▶	Right / I ▷	▶	RIGHT
OK	Ok	OK	OK
PLAY MODE -REPEAT	Play Mode	TV/R	TV/R
RETURN	Return	BACK	BACK
SOUND -W.SRD	Sound/ W SRD	Audio	
SURROUND -SLEEP	Surround/ Sleep	Subt.	
CH SELECT	Ch Select	V-FOR	V-FOR
FL DISPLAY	FL Display	TEXT	TEXT

Original	Replacement