Original		Replacement	
	Power		Power
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
FUNCTION	Input Function	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI-SAT 0	0
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
SKIP	I<< Skip	PRESET-	I<< / Preset-
SCAN	<< Scan	TUNE-	<< / Tune-

Original		Replacement	
	>> Scan	TUNE+	>> / Tune+
SKIP	>>I Skip	PRESET+	>>I / Preset+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
SPEAKER LEVEL	Speaker Level	OPT-TOOLS SETUP	Setup / OPT /
VOL	Vol +	VOL	Vol +
OPTICAL/TV SOUND	Optical/Tv Sound	LIST SMART	Smart / List
SOUND EFFECT	Sound Effect	SHIFT + TITLE SOUND	Shift + Sound / Title
VOL	Vol -	VOL	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
HOME	Home	HOME MENU	Menu / Home
3D SOUND	3D Sound	SHIFT + CD-STB 3	Shift + 3
INFO/MENU	Info/Menu	SHIFT + HOME MENU	Shift + Menu /
INFO/MENU	Info/Menu	ANGLE INFO	Info / Angle
TUNING	Left/Tuning-		Left
TUNING	Left/Tuning-	SHIFT + TUNE-	Shift + << / Tune-

Original	Replacement
Up/Preset+	Up
Up/Preset+	SHIFT + PRESET+ Shift + >>I / Preset+
Enter	OK
Right/Tuning+	Right
Right/Tuning+	SHIFT + TUNE+ Shift + >> /
Down/Preset-	Down
Down/Preset-	SHIFT + PRESET- Shift + I<< / Preset-
Back	RETURN BACK Back / Return
Title/Pop Up	TITLE SOUND Sound / Title
Disc Menu	TOP MENU D.MENU D.Menu / Top
Red/RDS	NETFLIX SEARCH Red / Netflix / Search
Red/RDS	SHIFT + RDS AV INPUT Shift + AV / Input / RDS
Green/PTY	APP REPEAT Green / APP / Repeat
Yellow/PTY Searc	YouTube REPEAT A-B Yellow / YouTube / Repeat
Blue/Mono/Stereo	Prime Video RANDOM Blue / Prime Video / Random
Subtitle	EQ SUBTITLE Subtitle / EQ
Audio	LANG I/II AUDIO Audio / Lang I/II

Original	Replacement
Sleep	TIMER SLEEP Sleep / Timer
Music ID	GOTO TEXT Text / Goto
Power TV	SHIFT + Power Shift + Power
VOL+ Vol + Tv	SHIFT + VOL Shift + Vol +
PR/CH CH+ Tv	CH PAGE CH+ / Page+
AV/INPUT AV Input Tv	RDS AV INPUT AV / Input / RDS
VOL- Vol - Tv	SHIFT + VOL Shift + Vol -
PR/CH CH- Tv	CH PAGE CH- / Page-