Original		Replacement	
Power	Power	Power	Power
Mute	Mute	MUTE	Mute
DISPLAY	Display	DISPLAY INFO	Info
MODE	Mode	DISC NAV LIST	List
TIMER	Timer	TIMER AV	AV
TV/R	TV/R	SEARCH TV/R	TV/R
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SAT	SAT	E-MANUAL D.MENU	D. Menu

Original		Replacement	
F1	F1	SHIFT + 1	Shift + 1
FUNC	FUNC	ECO 3D	3D
SUB	Sub	AD SUBT	Subt
[++]	[++]	PICTURE FORMAT	Format
TXT	TXT	REPEAT TEXT	Text
FIND	Find	SHIFT + SEARCH TV/R	Shift + TV/R
EPG	EPG	-/-- GUIDE	Guide
PAUSE	Pause	SHIFT + II	Shift + Pause
SLEEP	Sleep	PROG SLEEP	Sleep
AUDIO	Red/Audio	A	Red
RECALL	Green/Recall	B	Green
ZOOM	Yellow/Zoom	C	Yellow
INFO	Blue/Info	D	Blue
FAV	FAV	FAV PRE-CH	Pre Ch
HELP	Help	SOUND DUAL	Dual
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit

Original	Replacement
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Back	Back
USB	Media
Vol +	Vol +
Vol -	Vol -
Page+	Ch +
Page-	Ch -
<<	<<
>>	>>
I <<	I <<
>>I	>>I
Play	Play
Pause	Pause

Original	Replacement
Stop	Stop
Rec	Rec
F2	SHIFT + 2 (Shift + 2)
F3	SHIFT + 3 (Shift + 3)
F4	SHIFT + 4 (Shift + 4)
F5	SHIFT + 5 (Shift + 5)