| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Power TV | SHIFT + | Shift + Power |
| | Eject | SURROUND | Eject / Surround |
| TTX/MIX | TTX/MIX | GOTO TEXT | Text / Goto |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| DISC MENU | Disc Menu | TOP MENU D.MENU | D.Menu / Top |
| 0 | 0 | HDMI - SAT 0 | 0 |
| TITLE MENU POPUP | Popup/Title Menu | PC FAV MARKER | Fav / Marker / PC |
| | I<< | PRESET- | I<< / Preset- |

| Original | | Replacement | |
|---|---|---|---|
| | >>I | PRESET+ | >>I / Preset+ |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | Stop | HOLD | Stop / Hold |
| | Play | SLOW | Play / Slow |
| | Pause | STEP - FREEZE | Pause / Step / Freeze |
| TV VOL | Vol+ | VOL | Vol+ |
| TV MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| PROG | Prog+ | CH PAGE | CH+ / Page+ |
| TV VOL | Vol- | VOL | Vol- |
| TV SOURCE | Source | RDS AV INPUT | AV / Input / RDS |
| PROG | Prog- | CH PAGE | CH- / Page- |
| CH LIST | [≡♦]CH List | SHIFT + LIST SMART | Shift + Smart / List |
| HOME | Home | HOME MENU | Menu / Home |
| GUIDE | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |
| TOOLS | Tools | OPT-TOOLS SETUP | Setup / OPT / |
| | Up | | Up |

| Original | | Replacement | |
|---|---|---|---|
| INFO | Info | ANGLE INFO | Info / Angle |
| ◄ | Left | ◄ | Left |
| ↵ | Enter | OK | OK |
| ► | Right | ► | Right |
| RETURN | Return | RETURN BACK | Back / Return |
| ▼ | Down | ▼ | Down |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| A | Red/A | NETFLIX SEARCH | Red / Netflix / Search |
| B | Green/B | APP REPEAT | Green / APP / Repeat |
| C | Yellow/C | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| D | Blue/D | Prime Video RANDOM | Blue / Prime Video / Random |
| SMART HUB | Smart Hub | LIST SMART | Smart / List |
| SEARCH | Search | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| E-MANUAL | E-Manual | TIMER SLEEP | Sleep / Timer |
| SOCIAL TV | Social TV | PROGRAM TV/ RADIO | TV/Radio / |
| WEB BROWSER | Web Browser | MEDIA DISPLAY | Display / Media |
| 3D | 3D | FORMAT PICTURE | Picture / Format |

| Original | | Replacement | |
|---|---|---|---|
| REC ● | Rec | REC MODE ● | Rec / Rec Mode |
| REC PAUSE ❚❚ | Rec Pause | SHIFT + REC MODE ● | Shift + Rec / Rec Mode |

| Original | | Replacement | |
|---|---|---|---|
| TV | Power Tv | | Power |
| TTX/MIX | TTX/MIX | GOTO TEXT | Text / Goto |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| I<< | I<< | PRESET- | I<< / Preset- |
| >>I | >>I | PRESET+ | >>I / Preset+ |
| << | << | TUNE- | << / Tune- |
| >> | >> | TUNE+ | >> / Tune+ |
| Stop | Stop | HOLD | Stop / Hold |

| Original | | Replacement | |
|---|---|---|---|
| | Play | SLOW | Play / Slow |
| TV VOL + | Vol+ | VOL + | Vol+ |
| TV MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| PROG | Prog+ | CH PAGE + | CH+ / Page+ |
| TV VOL − | Vol- | VOL − | Vol- |
| TV SOURCE | Source | RDS AV INPUT | AV / Input / RDS |
| PROG | Prog- | CH PAGE − | CH- / Page- |
| CH LIST | [≡♦]/CH List | SHIFT + LIST SMART | Shift + Smart / List |
| HOME | Home | HOME MENU | Menu / Home |
| GUIDE | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |
| TOOLS | Tools | OPT-TOOLS SETUP | Setup / OPT / |
| | Up | | Up |
| INFO | Info | ANGLE INFO | Info / Angle |
| | Left | | Left |
| | Enter | OK | OK |
| | Right | | Right |
| RETURN | Return | RETURN BACK | Back / Return |

| Original | | Replacement | |
|---|---|---|---|
| | Down | | Down |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| A | Red/A | NETFLIX SEARCH | Red / Netflix / Search |
| B | Green/B | APP REPEAT | Green / APP / Repeat |
| C | Yellow/C | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| D | Blue/D | Prime Video RANDOM | Blue / Prime Video / Random |
| SMART HUB | Smart Hub | LIST SMART | Smart / List |
| SEARCH | Search | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| 3D | 3D | FORMAT PICTURE | Picture / Format |
| REC | Rec | REC MODE | Rec / Rec Mode |
| REC PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |