Original		Replacement	
	Power		Power
	Open/Close	ZOOM	Eject
F	F	TOP MENU MENU	Menu
VOL +	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
PRESET FOLDER	Preset / Folder	+ CH	Ch +
PRESET FOLDER	Preset / Folder Down	CH –	Ch -
PROGRAM /MEMORY	Program /	SETTINGS OPT	Options
AUTO DJ	Auto DJ	ECO 3D	3D
DELETE	Delete	CLEAR EXIT	Exit
REPEAT	Repeat	REPEAT TEXT	Text
TUNING –	I<< / Tuning -	I<<	I<<
TUNING +	>>I / Tuning +	>>I	>>I
▶/II	Play	PLAY MODE ▶	Play
▶/II	Pause	II	Pause
■	Stop	■	Stop

Original		Replacement	
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
REGION EQ	Region EQ	AD SUBT	Subt
INFO	Info	DISPLAY INFO	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLOCK	Clock	SHIFT + TIMER AV	Shift + AV
ALARM	Alarm	SEARCH TV/R	TV/R
VOICE CANCELLER	Voice Cancelle	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Replacement	
RDS/SET	RDS / Set	APP MEDIA	Media
USB REC	USB Rec	REC MODE	Rec
PTY	PTY	PICTURE FORMAT	Format
#	Key Changer #	A	Red
♭ KEY CHANGER	Key Changer b	B	Green

Original	Replacement