Mandis shop

Samsung AH59-02546B

Original		Replacement	
POWER	Power		Power
TV POWER	Tv Power	SHIFT +	Shift + Power
TV VOL +	Tv Vol +	SHIFT + VOL +	Shift + Vol +
TV VOL −	Tv Vol -	SHIFT + VOL −	Shift + Vol -
TV CH	Tv CH+	CH +	Ch +
TV CH	Tv CH-	CH −	Ch -
TV SOURCE	Tv Source	SEARCH TV/R	TV/R
SOURCE	Source	TIMER AV	AV
REPEAT	Repeat	REPEAT TEXT	Text
Anynet+	Anynet*	APP MEDIA	Media
SoundShare	SoundShare	SETTINGS OPT	Options
SPEAKER	Speaker	-/-- GUIDE	Guide
AUTO POWER	Auto Power	PROG SLEEP	Sleep
TV MUTE	Tv Mute	SHIFT + MUTE	Shift + Mute
TV INFO	Tv Info	DISPLAY INFO	Info
TV PRE-CH	Tv Pre-CH	FAV PRE-CH	Pre Ch
TV EXIT	Tv Exit	CLEAR EXIT	Exit

Original		Replacement	
VOL +	Vol +	+ VOL	Vol +
S/W LEVEL >	>S/W Level		Right
MUTE	Mute	MUTE	Mute
VOL −	Vol -	VOL −	Vol -
S/W LEVEL <	< S/W Level		Left
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
DRC	DRC	PICTURE FORMAT	Format
SMART VOLUME	Smart Volume	HOME SMART	Smart
3D SOUND PLUS	3D Sound Plus	ECO 3D	3D
+ AUDIO SYNC	Audio Sync+		Up
AUDIO SYNC −	Audio Sync-		Down
	Stop		Stop
	I<<		I<<
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I

https://remotecontrols.de/Samsung/1035600-replacement-remote-control-for-Samsung-AH59-02546B.htm