Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
CANCEL	Cancel	GUIDE	Guide
AUDIO	Audio	SOUND DUAL	Dual
SELECTOR	Selector	AD SUBT	Subt

Original		Replacement	
PAIRING	Bluetooth/-Pairi	FAV PRE-CH	Pre Ch
PIP	PIP	ECO 3D	3D
SEARCH	<< Search	<<	<<
PLAY	Play	PLAY MODE	Play
SEARCH	Search >>	>>	>>
SKIP	I<< Skip	I<<	I<<
SLOW PAUSE	Pause		Pause
SKIP	Skip >>I	>>I	>>I
STOP	Stop		Stop
STATUS	Status	SEARCH TV/R	TV/R
EXIT	Exit	CLEAR EXIT	Exit
OPTION	Option	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
HOME	Home	HOME SMART	Smart
INTERNET	Internet	APP MEDIA	Media
POP-UP MENU / TOP MENU	Pop-Up Menu/Top Menu	TOP MENU MENU	Menu
	Up		Up

Original	Replacement
Down	Down
Right / I >	Right
Left	Left
OK	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Sleep	Sleep
Sound	Shift + Dual
Settings	Shift + Options
AV Input Tv	AV
Power Tv	Shift + Power
Vol + Tv	Shift + Vol +
Vol - Tv	Shift + Vol -

Original	Replacement