Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
POWER	POWER		Power
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10	+10	GUIDE EPG	Guide / EPG / -/--
LOUDNESS	LOUDNESS / PAGE DOWN	SHIFT + VOL −	Shift + Vol -
PTY	RECEIVER PTY / PAGE UP	SHIFT + VOL +	Shift + Vol +
MENU / SET UP	MENU / SET UP	HOME MENU	Menu / Home
OSD / SOUND	OSD / SOUND	SHIFT + TITLE SOUND	Shift + Sound / Title
RETURN / LISTEN MODE	RETURN / LISTEN MODE	RETURN BACK	Back / Return

Original		Replacement	
TOP MENU / RDS DISPLAY	TOP MENU / RDS DISPLAY	TOP MENU D.MENU	D. Menu / Top
P.CALL	LEFT / I<< / P. CALL -		Left
	MULTI CONTROL		Up
P.CALL	RIGHT / >>I / P. CALL +		Right
	MULTI CONTROL		Down
TUN	<< TUNING	TUNE-	<< / Tune-
NING	TUNING >>	TUNE+	>> / Tune+
ENTER	ENTER / Play reverse	OK	OK
BAND ▶/II	BAND / PLAY /	SLOW	Play / Slow
BASS BOOST	BASS BOOST	LANG I/II AUDIO	Audio / Lang I/II
A/B+100 DISC SKIP	A/B+100 / DISC	YouTube REPEAT A-B	Yellow / YouTube / Repeat
A/B+100 DISC SKIP	+100 / DISC SKIP / A/B	PC FAV MARKER	Fav / Marker / PC
AUTO	AUTO / STOP	HOLD	Stop / Hold
DVD	DVD / DVD	STEP-FREEZE	Pause / Step / Freeze
AUX	AUX / DVD I<<	SHIFT +	Shift + Left
CD/DVD	CD/DVD / DVD	SHIFT +	Shift + Right
TUNER DISC SEL	TUNER / DISC SEL.	SHIFT + TUNER 6	Shift + 6

Original	Replacement	Original	Replacement
MD/TAPE	SHIFT + TAPE 5 Shift + 5		
DVD SKIP PREV.	PRESET- I<< / Preset-		
VIDEO1	SHIFT + TV 1 Shift + 1		
DVD SKIP NEXT	CLEAR EXIT CANCEL Exit / Cancel / Clear		
VIDEO2	SHIFT + DVD 2 Shift + 2		
CINEMA EQ	NETFLIX SEARCH Red / Netflix / Search		
TONE	TITLE SOUND Sound / Title		
MUTE	DIMMER MUTE Mute / Dimmer		
VOLUME-	VOL − Vol -		
VOLUME+	+ VOL Vol +		