Mandis shop

COV30748163

Original		Replacement	
	Power		Power
FUNCTION	Function	TOP MENU MENU	Menu
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
	Equalizer	HOME SMART	Smart
WOOFER LEVEL	Woofer Level	CH +	Ch +
WOOFER LEVEL	Woofer Level	CH −	Ch -
DRC	DRC	APP MEDIA	Media
REPEAT	Repeat	REPEAT TEXT	Text
	Moon	FAV PRE-CH	Pre Ch
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
>>I	>>I	>>I	>>I
I<<	I<<	I<<	I<<
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
■	Stop	■	Stop

Original		Replacement	
+ FOLDER	Folder +	▲	Up
FOLDER −	Folder -	▼	Down
AV.SYNC	AV Sync	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
VOLUME AUTO	Auto Volume	0	0
AUTO POWER	Auto Power	-/-- GUIDE	Guide
OPTICAL	Optical	SETTINGS OPT	Options
USB	USB	AD SUBT	Subt
	Bluetooth	ECO 3D	3D
LG TV	LG Tv	SEARCH TV/R	TV/R
PORT.IN	Port.In	PICTURE FORMAT	Format
INFO	Info	DISPLAY INFO	Info

https://remotecontrols.com/LG/105418806-replacement-remote-control-for-LG-COV30748163.html