Original	Replacement	Original	Replacement
Standby/On	Power	Left	Left
1	1	Menu	Menu
2	2	Vol +	Vol +
3	3	Vol -	Vol -
4	4	Mute	Mute
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
P+	Ch +		
P-	Ch -		
Status/Exit	Exit		
Up	Up		
Down	Down		
Right	Right		

Original	Replacement	Original	Replacement
Standby/On	Power	Down	Down
Rec	Rec	Right	Right
1	1	Left	Left
2	2	Play	Play
3	3	Stop	Stop
4	4	>>	>>
5	5	<<	<<
6	6	Menu	Menu
7	7	Vol +	Vol +
8	8	Vol -	Vol -
9	9	>I</Still	Pause
0	0	Mute	Mute
P+	Ch +	>I/Index	Text
P-	Ch -	Slow	AV
Status/Exit	Exit	System	Media
Clear	Shift + Exit	Turbo Timer	Options
Up	Up	SV/N+	Format

Original	Replacement	Original	Replacement
SMART PICTURE Smart Picture	ECO 3D 3D		
AUDIO Audio	SOUND DUAL Dual		