Original		Replacement	
POWER	Power		Power
CLOCK	Clock	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CD	CD	SHIFT + CD-STB 3	Shift + 3
ANALOG IN	Analog In	TOP MENU D.MENU	D. Menu / Top
OPTICAL IN	Optical In	OPT-TOOLS SETUP	Setup / OPT /
FM	FM	LIST SMART	Smart / List
AM	AM	MEDIA DISPLAY	Display / Media
Bluetooth	Bluetooth	SHIFT + BLUETOOTH 9	Shift + 9
⏮	I <<	PRESET- ⏮	I << / Preset-
►/II	Play	SLOW ▶	Play / Slow
►/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
⏭	>>I	PRESET+ ⏭	>>I / Preset+
TUNE – ◄◄	<<I Tune-	TUNE- ◄◄	<< / Tune-
■	Stop	HOLD ■	Stop / Hold
TUNE + ►►	>>I Tune+	TUNE+ ►►	>> / Tune+
PRESET	Preset+	SHIFT + PRESET+ ⏭	Shift + >>I / Preset+

Original		Replacement	
TONE	Tone	RDS AV INPUT	AV / Input / RDS
VOLUME ▲	Volume+	+ VOL	Vol +
PRESET –	Preset-	SHIFT + PRESET- ⏮	Shift + I << / Preset-
🔇	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME ▼	Volume-	VOL –	Vol -
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
INFO	Info	ANGLE INFO	Info / Angle
▲	Up	▲	Up
◄	Left	◄	Left
ENTER	Enter	OK	OK
►	Right	►	Right
BACK	Back	RETURN BACK	Back / Return
▼	Down	▼	Down
TIMER MENU	Timer Menu	HOME MENU	Menu / Home
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio / Program

Original		Replacement		Original	Replacement
MODE	Mode	FORMAT PICTURE	Picture / Format		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		