Original		Replacement	
TV DIRECT	TV Direct	LIST SMART	Smart / List
DVD	Power DVD	NETFLIX SEARCH	Red / Netflix / Search
VCR	Power VCR	APP REPEAT	Green / APP / Repeat
Power Audio			Power
STB	Power STB	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TV	Power TV	Prime Video RANDOM	Blue / Prime Video / Random
DVD	DVD	DVD 2	2
VCR	VCR	VIDEO 4	4
TV	TV	TV 1	1
FM/AM	FM/AM	TUNER 6	6
TV/VIDEO	Tv/Video	TAPE 5	5
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CHANNEL +	Channel +	CH PAGE +	CH+ / Page+
VOLUME +	Volume+	VOL +	Vol +
Channel -		CH PAGE −	CH- / Page-
Volume-		VOL −	Vol -
ON SCREEN DISPLAY	Display/On Screen	MEDIA DISPLAY	Display / Media

Original		Replacement	
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ANALOG/DIGITAL INPUT	Analog/Digital Input	RDS AV INPUT	AV / Input / RDS
SMART S SETUP	Smart S Setup	OPT-TOOLS SETUP	Setup / OPT /
BASS BOOST	Bass Boost	LANG I/II AUDIO	Audio / Lang I/II
TONE	C. Tone	EQ SUBTITLE	Subtitle / EQ
A.POSITION	A. Position	TOP MENU D.MENU	D.Menu / Top
TEST	Test Tone	GOTO TEXT	Text / Goto
EFFECT	Effect	ANGLE INFO	Info / Angle
DECODE	Decode	PROGRAM TV/RADIO	TV/Radio /
SURROUND	Surround	SURROUND ⏏	Eject / Surround
SUBWFR +	Subwfr+	▶	Right
CENTER +	Center+	▲	Up
L-SUR +	Surr L+	SHIFT + VOL +	Shift + Vol +
SURR-R +	Surr R+	SHIFT + CH PAGE +	Shift + CH+ /
−	Subwfr-	◀	Left
−	Center-	▼	Down

Original	Replacement	Original	Replacement
Surr L-	SHIFT + VOL – Shift + Vol -		
Surr R-	SHIFT + CH PAGE – Shift + CH+ /		

Original	Replacement
Power Audio	Power
Power Tv	SHIFT + Power
FM/AM	SURROUND Eject / Surround
Tv Vol +	VOL + Vol +
Channel + TV	CH + / Page+
Tv Vol -	VOL - Vol -
Channel - TV	CH - / Page-
Tuning- FM/AM	TUNE- << / Tune-
FM Mode FM/AM	LIST SMART Smart / List
Tuning+ FM/AM	TUNE+ >> / Tune+
Memory FM/AM	HOME MENU Menu / Home
TA/News/Info	ANGLE INFO Info / Angle
TA/News/Info	Up
PTY- FM/AM	Left
PTY+ FM/AM	Right
PTY Search	Down
PTY Search	NETFLIX SEARCH Red / Netflix / Search

Original	Replacement
ON SCREEN DISPLAY Display FM/AM	MEDIA DISPLAY Display / Media
1 FM/AM	SHIFT + TV 1 Shift + 1
1 TV	TV 1 1
BASS 2 FM/AM	SHIFT + DVD 2 Shift + 2
BASS 2 TV	DVD 2 2
TREBLE 3 FM/AM	SHIFT + CD-STB 3 Shift + 3
TREBLE 3 TV	CD-STB 3 3
4 FM/AM	SHIFT + VIDEO 4 Shift + 4
4 TV	VIDEO 4 4
BASS 5 FM/AM	SHIFT + TAPE 5 Shift + 5
BASS 5 TV	TAPE 5 5
TREBLE 6 FM/AM	SHIFT + TUNER 6 Shift + 6
TREBLE 6 TV	TUNER 6 6
7 FM/AM	SHIFT + AUX-HDD 7 Shift + 7
7 TV	AUX-HDD 7 7
8 FM/AM	SHIFT + USB 8 Shift + 8
8 TV	USB 8 8

Original	Replacement	Original	Replacement
9 FM/AM	SHIFT + 9		
9 TV	9		
10 FM/AM	SHIFT + FAV / Marker / PC		
10/Tv Return TV	SHIFT + 0		
0 TV	0		
+10/100+	SHIFT + Guide / EPG / -/--		
+10 TV	Fav / Marker / PC		

Original		Replacement	
	Power DVD		Power
	I <<		I << / Preset-
	Play		Play / Slow
	>>I		>>I / Preset+
	<<		<< / Tune-
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Top Menu		D. Menu / Top
	>>		>> / Tune+
	Up		Up
	Menu		Menu / Home
	Left		Shift + Left
	Enter		OK
	Right		Right
	Set Up		Setup / OPT /
	Down		Down
	On Screen		Shift + Display / Media

Original		Replacement	
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Title Group		Shift + Sound / Title
	Return		Back / Return
	DVD Zoom		Zoom / Size
	1		1
	2		2
	3		3
	VFP Progressive		Smart / List
	4		4
	5		5
	6		6
	←		Left
	7		7
	8		8
	9		9
	Angle		Info / Angle

Original		Replacement		Original	Replacement
TV RETURN 10	10	GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
100+ +10	+10	PC FAV MARKER	Fav / Marker / PC		
DIMMER	Display/Dimmer	MEDIA DISPLAY	Display / Media		
ANALOG/DIGITAL INPUT	Input Analog/Digital	RDS AV INPUT	AV / Input / RDS		
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
EFFECT	HDD Sound Effect	TITLE SOUND	Sound / Title		
SURROUND	Surround	SURROUND	Eject / Surround		

Original	Replacement
Power VCR	SHIFT + Power (Shift + Power)
Power STB	Power
VCR	SHIFT + GUIDE EPG (Shift + Guide / EPG / -/--)
Muting	DIMMER MUTE (Mute / Dimmer)
Channel +	CH+ / Page+
Volume+	Vol +
Channel -	CH- / Page-
Volume-	Vol -
Play VCR	SLOW (Play / Slow)
<< VCR	TUNE- (<< / Tune-)
Stop/Memory	HOLD (Stop / Hold)
Pause VCR	STEP-FREEZE (Pause / Step / Freeze)
>> VCR	TUNE+ (>> / Tune+)
1 VCR	SHIFT + TV 1 (Shift + 1)
1 STB	TV 1 (1)
2 VCR	SHIFT + DVD 2 (Shift + 2)
2 STB	DVD 2 (2)

Original	Replacement
3 VCR	SHIFT + CD-STB 3 (Shift + 3)
3 STB	CD-STB 3 (3)
4 VCR	SHIFT + VIDEO 4 (Shift + 4)
4 STB	VIDEO 4 (4)
5 VCR	SHIFT + TAPE 5 (Shift + 5)
5 STB	TAPE 5 (5)
6 VCR	SHIFT + TUNER 6 (Shift + 6)
6 STB	TUNER 6 (6)
7 VCR	SHIFT + AUX-HDD 7 (Shift + 7)
7 STB	AUX-HDD 7 (7)
8 VCR	SHIFT + USB 8 (Shift + 8)
8 STB	USB 8 (8)
9 VCR	SHIFT + BLUETOOTH 9 (Shift + 9)
9 STB	BLUETOOTH 9 (9)
+10 TV	GUIDE EPG (Guide / EPG / -/--)
0 VCR	SHIFT + HDMI-SAT 0 (Shift + 0)
0 STB	HDMI-SAT 0 (0)