Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
	Rec	REC MODE	Rec
GOTO	Goto	HOME SMART	Smart
ASPECT	Aspect	ECO 3D	3D
V.FORMAT	V. Format	PICTURE FORMAT	Format
	<<		<<
	>>		>>
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
AUDIO	Audio	SOUND DUAL	Dual
DEV	Dev	SETTINGS OPT	Options
RECALL	Recall	RETURN BACK	Back
TTX	Red/TTX	A	Red
SUB.T	Green/SUB.T	B	Green

Original		Replacement	
ZOOM	Yellow/Zoom	C	Yellow
OPTION	Blue/Option	D	Blue
INFO	Info	DISPLAY INFO	Info
FAV	FAV	FAV PRE-CH	Pre Ch
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
CH+	Up/CH+		Up
CH-	Down/CH-		Down
VOL+	Right/Vol +		Right
VOL-	Left/Vol -		Left
OK	OK	OK	Ok
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
SAT	SAT	APP MEDIA	Media
EPG	EPG	-/-- GUIDE	Guide
+ PAGE	Page+	+ CH	Ch +
PAGE –	Page-	CH –	Ch -

Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FIND	Fi nd	TIMER AV	AV
MP	MP	DISC NAV LIST	Li st

Original	Replacement