Mandis shop

Sony RM-DX100

Original		Replacement	
DISC	Disc	A	Red
TRACK	Track	B	Green
GROUP	Group	C	Yellow
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10/0	10/0	0	0
ENTER	Enter	OK	Ok
CONTINUE	Continue	▶	Right
SHUFFLE	Shuffle	▼	Down
PROGRAM	Program	◀	Left

Original		Replacement	
PROGRAM	Program	PROG SLEEP	Sleep
REPEAT	Repeat	REPEAT TEXT	Text
REPEAT	Repeat	▲	Up
DISC –	Disc Skip -	CH –	Ch -
SKIP +	Disc Skip +	+ CH	Ch +
AMS ⏮	I<< AMS	⏮	I<<
AMS ⏭	AMS >>I	⏭	>>I
◀◀	<<	◀◀	<<
▶▶	>>	▶▶	>>
■	Stop	■	Stop
▷	Play	PLAY MODE ▶	Play
❚❚	Pause	❚❚	Pause
MEMO	Memo	APP MEDIA	Media
+	Line Out Level -	+ VOL	Vol +
– LINE OUT LEVEL	Line Out Level	VOL –	Vol -
JOG ON/OFF	Jog On/Off	HOME SMART	Smart
ENTER	Enter	FAV PRE-CH	Pre Ch

https://remotecontrols.de/Sony/10187-650-replacement-remote-control-for-Sony-RM-DX100-152411.htm