Mandis shop

Sony 200064

Original	Replacement	Original	Replacement
POWER	Power	Black Level	Back
INPUT	AV	ADVANCED IRIS	8
PIC. MODE -	4	COLOR SPACE	9
PIC. MOD. - STANDARD	5	COLOR TEMP	0
PIC. MODE -	6	WIDE MODE	Red
USER 1	1	RCP	Green
USER 2	2	ADJ. PIC.	Yellow
USER 3	3	SHARPNESS+	Smart
LENS	Info	SHARPNESS-	Media
RESET	Exit	BRIGHT. +	Vol +
MENU	Menu	BRIGHT. -	Vol -
UP	Up	CONTRAST+	Ch +
LEFT	Left	CONTRAST-	Ch -
ENTER	Ok		
RIGHT	Right		
DOWN	Down		
GAMMA	7		

CORRECTION

https://remotecontrols.dk/en/Sony/10634-1982-replacement-remote-control-for-Sony-RM-PJVW70-1870712.htm