Original	Replacement	Original	Replacement
Power	Power	Stop/Open/Clos	Stop
Red	Red	Stop/Open/Clos	Eject
Green	Green	>>	>>
Yellow	Yellow	<<	<<
Blue	Blue	>I	>>I
Pop Up Menu/Disc Menu	D. Menu	I<	I<<
Top Menu	Menu	1	1
Home	Smart	2	2
OK	Ok	3	3
Up	Up	4	4
Down	Down	5	5
Right	Right	6	6
Left	Left	7	7
Back	Back	8	8
≡/Options	Options	9	9
Play	Play	0	0
Pause	Pause	Subtitle	Subt

Original		Replacement	
AUDIO	Audio	SOUND DUAL	Dual

Original	Replacement