Mandis shop

RB- DA70

Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
TUNING–	I << Tuning-	PRESET-	I << Preset-
TUNING–	I << Tuning-	TUNE-	<< Tune-
0	0	0	0
TUNING+	>>I Tuning+	TUNE+	>> Tune+
TUNING+	>>I Tuning+	PRESET+	>>I Preset+
REPEAT/ FM MODE	Repeat / FM	APP REPEAT	Green / APP / Repeat
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP-FREEZE II	Pause / Step / Freeze

Original		Replacement	
MEMORY	Memory	NETFLIX SEARCH	Red / Netflix / Search
PRESET	Preset	YouTube REPEAT A-B	Yellow / YouTube / Repeat
■	Stop	HOLD ■	Stop / Hold
BAND	Band	Prime Video RANDOM	Blue / Prime Video / Random
VOL –	Vol -	VOL –	Vol -
VOL +	Vol +	+ VOL	Vol +

https://remotecontrols.dk/Sanyo/1638-947-replacement-remote-control-for-Sanyo-RB-DA70.htm