| Original | Replacement | Original | Replacement |
|---|---|---|---|
| System Power | Power | Play/Pause | Pause |
| Title/Character | List | Play/Pause MD | Ok |
| Time | AV | Play/Pause CD | Play |
| Random/RDS | Subt | Vol + | Vol + |
| Edit | Options | Vol - | Vol - |
| << Tuning | << | Disc Skip | TV/R |
| >> Tuning Up | >> | Call/Panel | Back |
| Enter Memory | Dual | Display | Info |
| Sleep | Sleep | 1 | 1 |
| Repeat/PTY | Text | 2 | 2 |
| Tuner | Smart | 3 | 3 |
| Tone/SDB | Format | 4 | 4 |
| Function | Menu | 5 | 5 |
| >>I/+/Preset | >>I | 6 | 6 |
| I<</-/Preset | I<< | 7 | 7 |
| Prog/Direct/Group CT | Media | 8 | 8 |
| Stop/Band | Stop | 9 | 9 |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 10 | 10 | 0 | 0 | | | | |
| +10 | +10 | GUIDE | Gui de | | | | |
| CLEAR | Cl ear | CLEAR EXIT | Exi t | | | | |
| | Tape < | | Lef t | | | | |
| | Tape > | | Ri ght | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |