Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TIMER MENU	Timer Menu	HOME MENU	Menu / Home
DISPLAY	Display	MEDIA DISPLAY	Display / Media
I/⏻	Power	⏻	Power
CD	CD	TAPE 5	5
USB	USB	USB 8	8
BLUETOOTH	Bluetooth	BLUETOOTH 9	9
FM	FM	TUNER 6	6
AUDIO IN	Audio In	AUX - HDD 7	7
BLUETOOTH MENU	Bluetooth Menu	TOP MENU D.MENU	D. Menu / Top
1	Tuner Memory	TV 1	1
2	Tuner Memory	DVD 2	2
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
3	Tuner Memory	CD - STB 3	3
4	Tuner Memory	VIDEO 4	4
MEGA BASS	Mega Bass	TITLE SOUND	Sound / Title
TUNER MEMORY	Tuner Memory	REC MODE ●	Rec / Rec Mode

Original		Replacement	
TUNING +	Up/ Folder +	+ CH PAGE	CH+ / Page+
PLAY MODE/ TUNING MODE	Play Mode/ Tuning Mode	PROGRAM TV/ RADIO	TV/ Radio /
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
◀	Left	◀	Left
✥	OK	OK	OK
▶	Right	▶	Right
VOLUME +	Volume+	+ VOL	Vol +
RETURN	Return	RETURN BACK	Back / Return
TUNING –	Down/ Folder -	CH PAGE –	CH- / Page-
REPEAT/ FM MODE	Repeat / FM	APP REPEAT	Green / APP / Repeat
–	Volume-	VOL –	Vol -
PRESET– ⏮	⏮/ Preset -	PRESET- ⏮	⏮ / Preset -
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
PRESET+ ⏭	⏭/ Preset +	PRESET+ ⏭	⏭ / Preset +
TUNING– ◀◀	◀◀/ Tuning-	TUNE- ◀◀	◀◀ / Tune-
▶	Play	SLOW ▶	Play / Slow
TUNING+ ▶▶	▶▶/ Tuning+	TUNE+ ▶▶	▶▶ / Tune+

Original	Replacement	Original	Replacement
CLEAR Clear	CLEAR EXIT CANCEL Exit / Cancel / Clear		
Stop	HOLD Stop / Hold		