Original		Replacement	
POWER	Power		Power
FUNCTION TV SOURCE	Function	PROGRAM TV/RADIO	TV/Radio /
	Eject	SURROUND	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
RDS DISPLAY 1	1 / RDS Displa	TV 1	1
2	2	DVD 2	2
TA 3	3 / TA	CD-STB 3	3
PTY- 4	4 / PTY -	VIDEO 4	4
PTY SEARCH 5	5 / PTY Search	TAPE 5	5
PTY+ 6	6 / PTY +	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
FULL SCREEN	Full Screen	SIZE ZOOM	Zoom / Size
0	0	HDMI-SAT 0	0
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
	I<<	PRESET-	I<< / Preset-

Original		Replacement	
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
VOL +	Vol +	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	Tuning+ / CH +	CH PAGE +	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
V-SOUND	V-Sound	TITLE SOUND	Sound / Title
TUNING / CH	Tuning- / CH -	CH PAGE -	CH- / Page-
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top
MENU	Menu	HOME MENU	Menu / Home
TITLE MENU POPUP	Title Menu / PopUp Menu	SHIFT + HOME MENU	Shift + Menu /
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up

Original		Replacement		Original	Replacement
INFO	Info	ANGLE INFO	Info / Angle		
◀	Left	◀	Left		
Enter		OK	OK		
▶	Right	▶	Right		
RETURN	Return	RETURN BACK	Back / Return		
▼	Down	▼	Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
A	Red	NETFLIX SEARCH	Red / Netflix / Search		
B	Green	APP REPEAT	Green / APP / Repeat		
TUNER MEMORY C	Yellow / Tuner Memory	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
MO/ST D	Blue / Mo/St	Prime Video RANDOM	Blue / Prime Video / Random		
SMART HUB	Smart Hub	LIST SMART	Smart / List		
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /		
S/W LEVEL	S/W Level	EQ SUBTITLE	Subtitle / EQ		
DSP	DSP	MEDIA DISPLAY	Display / Media		
vTuner	vTuner	GOTO TEXT	Text / Goto		

Original		Replacement	
POWER	Power		Power
FUNCTION TV SOURCE	TV Source	RDS AV INPUT	AV / Input / RDS
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
RDS DISPLAY 1	1	TV 1	1
2	2	DVD 2	2
TA 3	3	CD-STB 3	3
PTY- 4	4	VIDEO 4	4
PTY SEARCH 5	5	TAPE 5	5
PTY+ 6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+

Original		Replacement	
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
VOL +	Vol +	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	CH+	CH PAGE +	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
TUNING / CH	CH-	CH PAGE -	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down

Original		Replacement		Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
A	Red	NETFLIX SEARCH	Red / Netflix / Search				
B	Green	APP REPEAT	Green / APP / Repeat				
TUNER MEMORY C	Yellow/Tuner	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
MO/ST D	Blue/Mo/St	Prime Video RANDOM	Blue / Prime Video / Random				
SMART HUB	Smart HUB	LIST SMART	Smart / List				
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /				