Original		Replacement	
POWER	Power	POWER	Power
CD	CD	CD - STB 3	3
SKIP	CD I<< Skip	PRESET-	I<< / Preset-
SKIP	CD Skip >>I	PRESET+	>>I / Preset+
PAUSE/STOP	CD Pause/Stop	HOLD	Stop / Hold
PAUSE/STOP	CD Pause/Stop	STEP - FREEZE	Pause / Step / Freeze
PLAY	CD Play	SLOW	Play / Slow
DISC SKIP	CD Disc Skip	SURROUND	Eject / Surround
TUNER	TUNER	TUNER 6	6
PRES	TUNER Preset-	CH PAGE -	CH- / Page-
ESET +	TUNER Preset+	+ CH PAGE	CH+ / Page+
A/B/C/D/E	TUNER	LIST SMART	Smart / List
TAPE	TAPE	TAPE 5	5
DECK A/B	TAPE Deck A/B	SHIFT + TITLE SOUND	Shift + Sound / Title
DIR A	TAPE Dir A	SHIFT + PRESET-	Shift + I<< / Preset-
PLAY	TAPE Play	SHIFT + SLOW	Shift + Play /
DIR B	TAPE Dir B	SHIFT + PRESET+	Shift + >>I / Preset+

Original		Replacement	
REC/PAUSE	TAPE Rec/Pause	SHIFT + STEP - FREEZE	Shift + Pause / Step /
REC/PAUSE	TAPE Rec/Pause	SHIFT + REC MODE	Shift + Rec / Rec Mode
<<	TAPE <<	SHIFT + TUNE-	Shift + << /
STOP	TAPE Stop	SHIFT + HOLD	Shift + Stop /
>>	TAPE >>	SHIFT + TUNE+	Shift + >> /
LD	LD	DVD 2	2
VCR 1	VCR 1	TV 1	1
VCR 2	VCR 2	VIDEO 4	4
AUX 1	V-AUX	AUX - HDD 7	7
TEST	Test	GOTO TEXT	Text / Goto
EFFECT	Effect On/Off	MEDIA DISPLAY	Display / Media
MASTER VOLUME +	Volume+	+ VOL	Vol+
–	Volume-	VOL –	Vol-

Original		Replacement	
POWER	Power	POWER	Power
CD	CD	CD - STB 3	3
TUNER	TUNER	TUNER 6	6
TAPE	TAPE	TAPE 5	5
LD	LD	DVD 2	2
HALL 1	Hall	SLOW	Play / Slow
CHURCH 2	Church	STEP - FREEZE	Pause / Step / Freeze
JAZZ CLUB 3	Jazz Club	HOLD	Stop / Hold
ROCK CNCT 4	Rock CNCT	REC MODE	Rec / Rec Mode
VCR 1	VCR 1	TV 1	1
CONCERT VIDEO 5	Concert Video	TUNE-	<< / Tune-
OPERA 6	Opera	TUNE+	>> / Tune+
CLASSIC FILM 7	Classic Film	PRESET-	I<< / Preset-
ANIMATION 8	Animation	PRESET+	>>I / Preset+
VCR 2	VCR 2	VIDEO 4	4
GAME 11	Game	SURROUND	Eject / Surround
KARAOKE 12	Karaoke	EQ SUBTITLE	Subtitle / EQ

Original		Replacement	
AUX 1	AUX 1	AUX - HDD 7	7
PRO LOGIC 15	Pro Logic	TITLE SOUND	Sound / Title
ENHANCED 16	Enhanced	LANG I/II AUDIO	Audio / Lang I/II
AUX 2	AUX 2	USB 8	8
TEST	Test	GOTO TEXT	Text / Goto
	Up		Up
MASTER VOLUME +	Vol+	+ VOL	Vol+
−	Left		Left
+	Right		Right
EFFECT	Effect	LIST SMART	Smart / List
	Down		Down
MUTING	Mute	DIMMER MUTE	Mute / Dimmer
−	Vol-	VOL −	Vol-