Mandis shop

RCTMB100

Original		Replacement	
	Power		Power
	Green/Timer/List	APP / REPEAT	Green / APP / Repeat
	Yellow/Info	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
	Blue/[^]	Prime Video / RANDOM	Blue / Prime Video / Random
	Red/[o]	NETFLIX / SEARCH	Red / Netflix / Search
	Up		Up
	Violet/Text	GOTO TEXT	Text / Goto
	Left		Left
	OK	OK	OK
	Right		Right
	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Menu	HOME MENU	Menu / Home
	Vol +	+ VOL	Vol +
	Down		Down
	PR+	+ CH PAGE	CH+ / Page+
	Mute	DIMMER MUTE	Mute / Dimmer
	Vol -	VOL –	Vol -

Original		Replacement	
	PR-	CH PAGE –	CH- / Page-
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	AV	RDS AV INPUT	AV / Input / RDS
	0/--	HDMI-SAT 0	0

https://remotecontrols.de/106139-204-replacement-remote-control-for-RCTMB10-28920.htm