Mandis shop

LG AKB36086232

Original	Replacement
POWER	Power
EQ	EQ
PRESET/FOLDER	Preset/Folder+
PRESET/FOLDER	Preset/Folder+
FUNCTION	Function
VOLUME	Volume+
	Preset/Folder-
	Preset/Folder-
MUTE	Mute
	Volume-
REPEAT /RANDOM	Repeat /
REPEAT /RANDOM	Repeat /
REPEAT /RANDOM	Repeat /
INFO	Info
TUN.–	<< / I<< / Tun
TUN.–	<< / I<< / Tun
TUN.–	<< / I<< / Tun

Replacement
Power
Subtitle / EQ
CH- / Page-
SHIFT + PRESET+ Shift + >>I / Preset+
HOME MENU Menu / Home
VOL + Vol +
CH PAGE CH+ / Page+
SHIFT + PRESET- Shift + I<< / Preset-
DIMMER MUTE Mute / Dimmer
VOL – Vol -
APP REPEAT Green / APP / Repeat
Prime Video RANDOM Blue / Prime Video / Random
Up
ANGLE INFO Info / Angle
PRESET- I<< / Preset-
TUNE- << / Tune-
Left

Original	Replacement
Stop	OK
Stop	HOLD Stop / Hold
TUN.+ >> / >>I /	PRESET+ >>I / Preset+
TUN.+ >> / >>I /	TUNE+ >> / Tune+
TUN.+ >> / >>I /	Right
PROGRAM /MEMO Program/Memo	PC FAV MARKER Fav / Marker / PC
PROGRAM /MEMO Program/Memo	PROGRAM TV/RADIO TV/Radio /
▶/II Play / Pause	SLOW Play / Slow
▶/II Play / Pause	Down
▶/II Play / Pause	STEP-FREEZE Pause / Step / Freeze
REC Rec	REC MODE Rec / Rec Mode
RDS RDS	MEDIA DISPLAY Display / Media
PTY PTY	LIST SMART Smart / List

https://remotes.de/LG/10696780-replacement-remote-control-for-LG-AKB36086232.htm