Mandis shop

Sony RMT-845

Original	Replacement	Original	Replacement
TC Reset	Exit / Cancel / Clear	Display	Display / Media
Data Code	Smart / List	Down	Down
Start/Stop	Power		
◁ Scan/Slow	<< / Tune-		
Scan/Slow I >	>> / Tune+		
T	CH+ / Page+		
I <<	I << / Preset-		
>>I	>>I / Preset+		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
W	CH- / Page-		
Stop	Stop / Hold		
Up	Up		
Mode	Picture / Format		
Left	Left		
Enter	OK		
Right	Right		

https://remotes.de/Sony/10647-953-replacement-remote-control-for-Sony-RMT-845-137503.htm