Mandis shop

Panasonic EUR648200

Original		Replacement	
	Power		Power
AUTO OFF	Auto Off	SHIFT +	Shift + Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
DISC	Disc	MEDIA DISPLAY	Display / Media
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
≥10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio / Program

Original		Replacement	
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
TAPE	Tape	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD - STB 3	Shift + 3
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
3D AI	3D AI	LIST SMART	Smart / List
⏮/◀◀	<<	TUNE- ◀◀	<< / Tune-
⏮/◀◀	I<<	PRESET- ⏮	I<< / Preset-
▶▶/▶▶I	>>I	PRESET+ ▶▶I	>>I / Preset+
▶▶/▶▶I	>>	TUNE+ ▶▶	>> / Tune+
V.BASS	V.Bass	TITLE SOUND	Sound / Title
◀/V	</▼	◀	Left
◀/V	</▼	▼	Down
◀/V	</▼	CH PAGE —	CH- / Page-

https://remotecontrols.dk/en/Panasonic/1066741-28823-replacement-remote-control-for-Panasonic-EUR648200.html

Original	Replacement	Original	Replacement
Stop	Stop / Hold		
Play/Pause/▲	Play / Slow		
Play/Pause/▲	Right		
Play/Pause/▲	Pause / Step / Freeze		
Play/Pause/▲	Up		
Play/Pause/▲	CH+ / Page+		
Volume-	Vol-		
Volume+	Vol+		