Original		Replacement	
	Power		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUTO OFF SLEEP	Auto Off	Prime Video RANDOM	Blue / Prime Video / Random
CLOCK/ TIMER DISPLAY	Display	MEDIA DISPLAY	Display / Media
CLOCK/ TIMER DISPLAY	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
PLAY/ REC DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
PLAY/ REC DIMMER	Timer Play/Rec	REC MODE	Rec / Rec Mode
DISC	Disc	TOP MENU D.MENU	D.Menu / Top
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PLAY MODE	Play Mode	FORMAT PICTURE	Picture / Format
PQRS 7	7	AUX - HDD 7	7

Original		Replacement	
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
DEL	Del	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI - SAT 0	0
SPACE !"# ≥10	>10	-/-- GUIDE EPG	Guide / EPG / -/--
CD ▶/II	Play/Pause CD	SLOW	Play / Slow
TUNER/ BAND	Tuner/Band	SHIFT + TUNER 6	Shift + 6
CLEAR	Stop/Clear	HOLD	Stop / Hold
TAPE	<> Tape	STEP - FREEZE	Pause / Step / Freeze
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
VOL –	Vol -	VOL –	Vol -
+ VOL	Vol +	+ VOL	Vol +
ALBUM	←ALbum	TUNE-	<< / Tune-
ALBUM	Album→	TUNE+	>> / Tune+
V/REW	I <<</ Down/Rew	PRESET-	I << / Preset-
Λ/FF	>>I / Up/FF	PRESET+	>>I / Preset+

Original		Replacement		Original	Replacement
INTRO	Intro	HOME MENU	Menu / Home		
MARKER	Marker	PC FAV MARKER	Fav / Marker / PC		
TITLE SEARCH	Title Search	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
ENTER	Enter	OK	OK		
RE-MASTER S.SOUND EQ	S. Sound EQ	GOTO TEXT	Text / Goto		
RE-MASTER S.SOUND EQ	Re-Master	EQ SUBTITLE	Subtitle / EQ		
SOUND	Sound	TITLE SOUND	Sound / Title		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		