Original		Replacement	
	Power		Power
1	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
LANG.	Lang	AUDIO	Audio / Lang I/II
0	0	0	0
TXT	TXT	TEXT	Text / Goto
V-	V-	VOL -	Vol -
V+	V+	VOL +	Vol +
	Mute	MUTE	Mute / Dimmer
P	P+	CH PAGE +	CH+ / Page+

Original		Replacement	
P	P-	CH PAGE -	CH- / Page-
	Source	AV INPUT	AV / Input / RDS
	Home	MENU	Menu / Home
	[G]	GUIDE EPG	Guide / EPG / -/--
i	i	INFO	Info / Angle
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
BACK	Back	BACK	Back / Return
EXIT	Exit	EXIT	Exit / Cancel / Clear
NETFLIX	Netflix	SHIFT + NETFLIX	Shift + Red / Netflix /
YouTube	YouTube	SHIFT + YouTube	Shift + Yellow / YouTube /
prime video	prime video	SHIFT + Prime Video	Shift + Blue / Prime
Rakuten TV	Rakuten Tv	PROGRAM TV/RADIO	TV/Radio /
twitch	twitch	SIZE ZOOM	Zoom / Size

Original		Replacement		Original		Replacement	
☆	☼1	OPT-TOOLS SETUP	Setup / OPT /				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
■	Stop	HOLD ■	Stop / Hold				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
●	Rec	REC MODE ●	Rec / Rec Mode				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				