Mandis shop

LSSQ0336

Original	Replacement	Original	Replacement
Start/Stop	Power	Zoom W	Down
Play	Play / Slow	Vol +	Vol +
Pause/Item	Pause / Step / Freeze	Counter	Smart / List
Stop/Set	Stop / Hold	Vol -	Vol -
Rec	Rec / Rec Mode	OSD	Display / Media
<<	<< / Tune-		
>>	>> / Tune+		
I<< Index	I<< / Preset-		
Index >>I	>>I / Preset+		
A DUB	Audio / Lang I/II		
Photo Shot	Picture / Format		
Date/Time	Sleep / Timer		
Menu	Menu / Home		
Zoom T	Up		
<I Still Adv	Left		
Still Adv I>	Right		
Reset	Exit / Cancel / Clear		

https://remotes.com/Panasonic/1066-145-replacement-remote-control-for-Panasonic-LSSQ0336.htm