Mandis shop

Samsung DJ 9600147F

Original		Replacement		Original	Replacement
Power	Power		Power		
Start	Start	SLOW	Play / Slow		
Stop	Stop	HOLD	Stop / Hold		
Recharging	Rechargi ng	SURROUND	Eject / Surround		
Max	Max	TOP MENU D.MENU	D. Menu / Top		
	Up		Up		
	Left		Left		
Start/Stop	Star/Stop	OK	OK		
	Right		Right		
Auto	Auto	LIST SMART	Smart / List		
Spot	Spot	MEDIA DISPLAY	Display / Media		
Manual	Manual A1	TV 1	1		
	Manual A2	DVD 2	2		
	Manual A3	CD - STB 3	3		
	Manual B1	VIDEO 4	4		
	Manual B2	TAPE 5	5		
	Manual B3	TUNER 6	6		