Original		Replacement	
EJECT	Eject	SURROUND	Eject / Surround
POWER	Power		Power
DISC	Disc	SHIFT + DVD 2	Shift + 2
RADIO	Radio	SHIFT + TUNER 6	Shift + 6
iPod	iPod	SHIFT + CD - STB 3	Shift + 3
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
A-B	A-B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
0	0	HDMI - SAT 0	0
FIND	Find	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
HOME	Home	HOME MENU	Menu / Home
SURROUND	Surround	SHIFT + SURROUND	Shift + Eject / Surround
OPTIONS	Options	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
POP-UP	Pop-Up	-/-- GUIDE EPG	Guide / EPG / -/--
	I<<	PRESET-	I<< / Preset-

Original		Replacement		Original		Replacement	
	>>I	PRESET+	>>I / Preset+				
	<<	TUNE-	<< / Tune-				
	>>	TUNE+	>> / Tune+				
	Stop	HOLD	Stop / Hold				
	Play	SLOW	Play / Slow				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Volume+	VOL +	Vol +				
	Mute	DIMMER MUTE	Mute / Dimmer				
	Channel +	CH PAGE +	CH+ / Page+				
	Volume-	VOL −	Vol -				
	Channel -	CH PAGE −	CH- / Page-				
	Red/Program	NETFLIX SEARCH	Red / Netflix / Search				
	Green/Bookmar	APP REPEAT	Green / APP / Repeat				
	Yellow/Thumbnail	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue/Zoom	Prime Video RANDOM	Blue / Prime Video / Random				

Original		Replacement	
EJECT	Eject	SURROUND	Eject / Surround
POWER	Power		Power
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
A-B	A-B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
0	0	HDMI - SAT 0	0
FIND	Find	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix / Search

Original		Replacement	
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
POP-UP	Pop-Up	-/-- GUIDE EPG	Guide / EPG / -/--
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
⏪	<<	TUNE- ⏪	<< / Tune-
⏩	>>	TUNE+ ⏩	>> / Tune+
■	Stop	HOLD ■	Stop / Hold
▶	Play	SLOW ▶	Play / Slow
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
VOLUME+	Volume+	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer

Original		Replacement		Original	Replacement
+ CHANNEL	Channel +	+ CH PAGE	CH+ / Page+		
VOLUME +	Volume+	VOL +	Vol +		
CHANNEL -	Channel -	CH PAGE -	CH- / Page-		
PROGRAM	Red/ Program	NETFLIX SEARCH	Red / Netflix / Search		
BOOKMARK	Green/ Bookmar	APP REPEAT	Green / APP / Repeat		
THUMBNAIL	Yellow/ Thumbnail	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
ZOOM	Blue/ Zoom	Prime Video RANDOM	Blue / Prime Video / Random		