Mandis shop

RC- 1264

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FM MODE/ PLAY MODE	FM Mode/ Play	LIST SMART	Smart / List
DISPLAY	Display	MEDIA DISPLAY	Display / Media
FUNCTION	Function	HOME MENU	Menu / Home
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
RECORD	Record	REC MODE	Rec / Rec Mode
TIMER	Timer	OK	OK
PROGRAM	Program	PROGRAM TV/ RADIO	TV/ Radio / Program

Original		Replacement	
ERASE	Erase	RETURN BACK	Back / Return
TUNING	I <</ <</ Tuning	PRESET-	I << / Preset-
TUNING	I <</ <</ Tuning	TUNE-	<< / Tune-
TUNING	>>/ >>I / Tuning	PRESET+	>>I / Preset+
TUNING	>>/ >>I / Tuning	TUNE+	>> / Tune+
MP3 FOLDER/ PRESET	MP3 Folder/ Preset Down	CH PAGE +	CH+ / Page+
FOLDER/ PRESET	MP3 Folder/ Preset Up	CH PAGE -	CH- / Page-
BAND	Stop/ Band	HOLD	Stop / Hold
▶/II	Play	SLOW	Play / Slow
▶/II	Pause	STEP - FREEZE	Pause / Step / Freeze
VOLUME	Vol +	VOL +	Vol +
STANDBY/ON	Standby/ On		Power
	Vol -	VOL -	Vol -
MUTING	Muting	DIMMER MUTE	Mute / Dimmer

https://remotecontrols.dk/en/Teac/10852-307-replacement-remote-control-for-Teac-RC-1264.htm