Original		Replacement	
POWER	Power		Power
P/N /AUDIO	P/N/Audio	LANG I/II AUDIO	Audio / Lang I/II
DVD/ USB/CARD	DVD/USB/Card	RDS AV INPUT	AV / Input / RDS
OSD	OSD	MEDIA DISPLAY	Display / Media
PROG	Prog	PROGRAM TV/ RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
ANGLE	Angle	ANGLE INFO	Info / Angle

Original		Replacement	
0	0	HDMI - SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
MARK/ V-MODE	Mark/V-Mode	PC FAV MARKER	Fav / Marker / PC
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
TITLE	Title	TITLE SOUND	Sound / Title
	Down		Down
PBC/ MENU	PBC/Menu	HOME MENU	Menu / Home
	Stop	HOLD	Stop / Hold
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOL-	Vol -	VOL	Vol -

Original		Replacement	
VOL+	Vol +	VOL	Vol +
▶II	Play	SLOW ▶	Play / Slow
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I <<	PRESET- ⏮	I << / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+

Original	Replacement