| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| digital | Digital | MEDIA DISPLAY | Display / Media | pty | PTY | GOTO TEXT | Text / Goto |
| theater modes / info | Yellow/Theater Modes/Info | YouTube REPEAT A-B | Yellow / YouTube / Repeat | down | Down | ▼ | Down |
| play | Power | ⏻ | Power | RDS / menu | Menu/RDS | HOME MENU | Menu / Home |
| tv | Tv | SHIFT + | TV 1 Shift + 1 | | Vol + | + VOL | Vol + |
| dvd | DVD | SHIFT + | DVD 2 Shift + 2 | | PR+/ >>I | + CH PAGE | CH+ / Page+ |
| stereo / ...ter | Green/Stereo/[.. | APP REPEAT | Green / APP / Repeat | | Vol - | VOL − | Vol - |
| delay / title | Blue/Delay/Titl | Prime Video RANDOM | Blue / Prime Video / Random | pr− | PR-/I << | CH PAGE − | CH- / Page- |
| center | Red/Center/Audio | NETFLIX SEARCH | Red / Netflix / Search | | Mute | DIMMER MUTE | Mute / Dimmer |
| up | Up | ▲ | Up | 1 | 1 | TV 1 | 1 |
| level | Violet/Level/Cam | PC FAV MARKER | Fav / Marker / PC | 2 | 2 | DVD 2 | 2 |
| tape | Tape | SHIFT + | TAPE 5 Shift + 5 | 3 | 3 | CD-STB 3 | 3 |
| sat/cab | SAT/CAB | SHIFT + | HDMI-SAT 0 Shift + 0 | 4 | 4 | VIDEO 4 | 4 |
| tuner | Tuner | SHIFT + | TUNER 6 Shift + 6 | 5 | 5 | TAPE 5 | 5 |
| video / vcr | Video/VCR | SHIFT + | VIDEO 4 Shift + 4 | 6 | 6 | TUNER 6 | 6 |
| − | Left/- | ◀ | Left | 7 | 7 | AUX-HDD 7 | 7 |
| | OK | OK | OK | 8 | 8 | USB 8 | 8 |
| + | Right/+ | ▶ | Right | 9 | 9 | BLUETOOTH 9 | 9 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Memo / Clear | Smart / List | | |
| 0 | 0 | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| digital | Digital | MEDIA DISPLAY | Display / Media | down | Down | | Down |
| theater modes / info | Yellow/Theater Modes/Info | YouTube REPEAT A-B | Yellow / YouTube / Repeat | RDS / menu | Menu/RDS | HOME MENU | Menu / Home |
| play | Power | | Power | + | Vol + | + VOL | Vol + |
| tv | TV | SHIFT + TV 1 | Shift + 1 | + pr+ | PR+/ >>I | PRESET+ | >>I / Preset + |
| dvd | DVD | SHIFT + DVD 2 | Shift + 2 | + pr+ | PR+/ >>I | + CH PAGE | CH+ / Page+ |
| stereo / ater | Green/Stereo/[.. | APP REPEAT | Green / APP / Repeat | − | Vol - | VOL − | Vol - |
| delay / title | Blue/Delay/Titl | Prime Video RANDOM | Blue / Prime Video / Random | − pr− | PR-/I << | PRESET- | I << / Preset - |
| center | Red/Center/Audio | NETFLIX SEARCH | Red / Netflix / Search | − pr− | PR-/I << | CH PAGE − | CH- / Page- |
| up / tr | Up | | Up | | Mute | DIMMER MUTE | Mute / Dimmer |
| level | Violet/Level/Cam | PC FAV MARKER | Fav / Marker / PC | 1 | 1 | TV 1 | 1 |
| tape | Tape | SHIFT + TAPE 5 | Shift + 5 | 2 | 2 | DVD 2 | 2 |
| sat/cab | SAT/CAB | SHIFT + HDMI - SAT 0 | Shift + 0 | 3 | 3 | CD - STB 3 | 3 |
| tuner | Tuner | SHIFT + TUNER 6 | Shift + 6 | 4 | 4 | VIDEO 4 | 4 |
| video / vcr | Video/VCR | SHIFT + VIDEO 4 | Shift + 4 | 5 | 5 | TAPE 5 | 5 |
| − | Left/- | | Left | 6 | 6 | TUNER 6 | 6 |
| | OK | OK | OK | 7 | 7 | AUX - HDD 7 | 7 |
| + | Right/+ | | Right | 8 | 8 | USB 8 | 8 |

| Original | | Replacement | |
|---|---|---|---|
| | 9 | | 9 |
| | Memo/Clear | | Smart / List |
| | 0 | | 0 |
| | << | | << / Tune- |
| | Play | | Play / Slow |
| | >> | | >> / Tune+ |
| | Rec | | Rec / Rec Mode |
| | Stop | | Stop / Hold |
| | Pause | | Pause / Step / Freeze |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Digital | MEDIA DISPLAY: Display / Media | PTY | GOTO TEXT: Text / Goto |
| Yellow/Theater Modes/Info | YouTube REPEAT A-B: Yellow / YouTube / Repeat | Down | Down |
| Power | Power | Menu/RDS | HOME MENU: Menu / Home |
| TV | SHIFT + TV 1: Shift + 1 | Vol + | VOL +: Vol + |
| DVD | SHIFT + DVD 2: Shift + 2 | PR+/ >>I | CH PAGE +: CH+ / Page+ |
| Green/Stereo/[.. | APP REPEAT: Green / APP / Repeat | Vol - | VOL −: Vol - |
| Blue/Delay/Titl | Prime Video RANDOM: Blue / Prime Video / Random | PR-/ I << | CH PAGE −: CH- / Page- |
| Red/Center/Audio | NETFLIX SEARCH: Red / Netflix / Search | Mute | DIMMER MUTE: Mute / Dimmer |
| Up | Up | 1 | TV 1: 1 |
| Violet/Level/Cam | PC FAV MARKER: Fav / Marker / PC | 2 | DVD 2: 2 |
| Tape | SHIFT + TAPE 5: Shift + 5 | 3 | CD-STB 3: 3 |
| SAT/CAB | SHIFT + HDMI-SAT 0: Shift + 0 | 4 | VIDEO 4: 4 |
| Tuner | SHIFT + TUNER 6: Shift + 6 | 5 | TAPE 5: 5 |
| Video/VCR | SHIFT + VIDEO 4: Shift + 4 | 6 | TUNER 6: 6 |
| Left/- | Left | 7 | AUX-HDD 7: 7 |
| OK | OK: OK | 8 | USB 8: 8 |
| Right/+ | Right | 9 | BLUETOOTH 9: 9 |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Memo/Clear | Smart / List | | |
| 0 | 0 | | |
| << | << / Tune- | | |
| Play | Play / Slow | | |
| >> | >> / Tune+ | | |
| Rec | Rec / Rec Mode | | |
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| digital | Digital | MEDIA DISPLAY | Display / Media | | Right / + | | Right |
| theater modes / info | Yellow/Theater Modes/Info | YouTube REPEAT A-B | Yellow / YouTube / Repeat | pty | PTY | GOTO TEXT | Text / Goto |
| | Power | | Power | down | Down | | Down |
| tv | Tv | SHIFT + TV 1 | Shift + 1 | RDS / menu | Menu/RDS | HOME MENU | Menu / Home |
| dvd | DVD | SHIFT + DVD 2 | Shift + 2 | RDS / menu | Menu/RDS | RDS AV INPUT | AV / Input / RDS |
| stereo | Green/Stereo/[.. | APP REPEAT | Green / APP / Repeat | | Vol + | + VOL | Vol + |
| delay / title | Blue/Delay/Titl | Prime Video RANDOM | Blue / Prime Video / Random | | PR+/ >>I | + CH PAGE | CH+ / Page+ |
| center | Red/Center/Audio | LANG I/II AUDIO | Audio / Lang I/II | | PR+/ >>I | PRESET+ | >>I / Preset+ |
| center | Red/Center/Audio | NETFLIX SEARCH | Red / Netflix / Search | | Vol - | VOL − | Vol - |
| up | Up | | Up | | PR-/ I << | CH PAGE − | CH- / Page- |
| level | Violet/Camera/Le | PC FAV MARKER | Fav / Marker / PC | | PR-/ I << | PRESET- | I << / Preset- |
| tape | Tape | SHIFT + TAPE 5 | Shift + 5 | | Mute | DIMMER MUTE | Mute / Dimmer |
| sat/cab | SAT/CAB | SHIFT + HDMI - SAT 0 | Shift + 0 | 1 | 1 | TV 1 | 1 |
| tuner | Tuner | SHIFT + TUNER 6 | Shift + 6 | 2 | 2 | DVD 2 | 2 |
| video / vcr | Video/VCR | SHIFT + VIDEO 4 | Shift + 4 | 3 | 3 | CD - STB 3 | 3 |
| − | Left/- | | Left | 4 | 4 | VIDEO 4 | 4 |
| | OK | OK | OK | 5 | 5 | TAPE 5 | 5 |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| | 6 | | 6 | | | | |
| | 7 | | 7 | | | | |
| | 8 | | 8 | | | | |
| | 9 | | 9 | | | | |
| | Memo/Clear | | Smart / List | | | | |
| | 0 | | 0 | | | | |
| | << | | << / Tune- | | | | |
| | Play | | Play / Slow | | | | |
| | >> | | >> / Tune+ | | | | |
| | Rec | | Rec / Rec Mode | | | | |
| | Stop | | Stop / Hold | | | | |
| | Pause | | Pause / Step / Freeze | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |