Mandis shop

Denon RC-282

Original		Replacement	
POWER	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10	10	0	0
+10	+10	GUIDE	Guide
CALL	Call	RETURN BACK	Back
EJECT	Eject	ZOOM	Eject
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original		Replacement	
REC	Rec	REC MODE	Rec
	>>I		>>I
	I <<		I <<
	>>		>>
	<<		<<
CLEAR	Clear	CLEAR EXIT	Exit
GROUP PROG/ DIRECT	Group/Prog/Direct	SETTINGS OPT	Options
REPEAT	Repeat	REPEAT TEXT	Text
RANDOM	Random	APP MEDIA	Media
EDIT	Edit	SEARCH TV/R	TV/R
ENTER	Enter	OK	Ok
TITLE	Title	DISPLAY INFO	Info
CHARACTER	Character	HOME SMART	Smart
TIME	Time	TIMER AV	AV

https://remotecontrols.com/Denon/1637-842-replacement-remote-control-for-Denon-RC-282-1398702.htm