Mandis shop

RC- 122

Original		Replacement	
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
AUX/VIDEO-1	AUX / VIDEO 1	TV 1	1
TUNER	TUNER	TUNER 6	6
CD	CD	CD-STB 3	3
PHONO	PHONO	AUX-HDD 7	7
TAPE-2/2▸1	TAPE 2 / 2 > 1	TAPE 5	5
TAPE-1/1▸2	TAPE-1 / 1 > 2	DVD 2	2
AUX/VIDEO-2	AUX / VIDEO 2	VIDEO 4	4
POWER	Power		Power
– VOLU	Volume-	VOL –	Vol -
UME +	Volume+	+ VOL	Vol +

Original	Replacement

https://remotecontrols.com/Denon/1080-976-replacement-remote-control-for-Denon-RC-122.htm