Mandis shop

Q120E

Original		Replacement	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
DISPLAY	Display	MEDIA DISPLAY	Display / Media
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
ROTATE	Rotate	RETURN BACK	Back / Return
TV SYSTEM	Tv System	PROGRAM TV/RADIO	TV/Radio /
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SLOW	Slow	SHIFT + SLOW	Shift + Play /
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
DEVICE	Device	RDS AV INPUT	AV / Input / RDS
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
INTERVAL	Interval	GOTO TEXT	Text / Goto
STOP	Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow
MENU	Menu	HOME MENU	Menu / Home

Original		Replacement	
MOVIE	Movie	LIST SMART	Smart / List
	Up		Up
MUSIC	Music	TITLE SOUND	Sound / Title
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
PHOTO	Photo	FORMAT PICTURE	Picture / Format
	Down		Down
FILE	File	ANGLE INFO	Info / Angle
	<<	TUNE-	<< / Tune-
VOL+	Vol +	VOL +	Vol +
	I <<	PRESET-	I << / Preset-
	>>	TUNE+	>> / Tune+
VOL-	Vol -	VOL -	Vol -
	>>I	PRESET+	>>I / Preset+

https://remotes.de/Woxter/1662-968-replacement-remote-control-for-Woxter-RC