Mandis shop

Hisense ERF3H80H

Original	Replacement	Original	Replacement
Power	Power	Blue	Blue
Input	AV	Play	Play
1	1	[=]	Menu
2	2	Pause	Pause
3	3	Back	Back
4	4	Exit	Exit
5	5	Up	Up
6	6	Down	Down
7	7	Right	Right
8	8	Left	Left
9	9	OK	Ok
0	0	Vol +	Vol +
Guide	Guide	Vol -	Vol -
CH. List	List	Home	Smart
Red	Red	Micro	Media
Green	Green	CH+	Ch +
Yellow	Yellow	CH-	Ch -

Original		Replacement		Original	Replacement
SUBTITLE	Subtitle	AD SUBT	Subt		
	Mute	MUTE	Mute		
TEXT	Text	REPEAT TEXT	Text		
FREE	Free	SETTINGS OPT	Options		
SPORTS	Sports	SEARCH TV/R	TV/R		
	[/]	ECO 3D	3D		
NETFLIX	Netflix	E-MANUAL D.MENU	D. Menu		
prime video	prime video	PICTURE FORMAT	Format		
YouTube	YouTube	SHIFT + HOME SMART	Shift + Smart		
Rakuten TV	Rakuten Tv	SOUND DUAL	Dual		
molotov.tv	molotov.tv	SHIFT + SEARCH TV/R	Shift + TV/R		
MEDIA	Media	SHIFT + APP MEDIA	Shift + Media		