Original		Replacement		Original		Replacement	
TV DIRECT	TV Direct	LIST SMART	Smart / List	DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
DVD	Power DVD	NETFLIX SEARCH	Red / Netflix / Search	SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
VCR	Power VCR	APP REPEAT	Green / APP / Repeat	ANALOG/DIGITAL INPUT	Analog/Digital Input	RDS AV INPUT	AV / Input / RDS
	Power Audio		Power	SMART S. SETUP	Smart S Setup	OPT-TOOLS SETUP	Setup / OPT /
STB	Power STB	YouTube REPEAT A-B	Yellow / YouTube / Repeat	BASS BOOST	Bass Boost	LANG I/II AUDIO	Audio / Lang I/II
TV	Power TV	Prime Video RANDOM	Blue / Prime Video / Random	TONE	C. Tone	EQ SUBTITLE	Subtitle / EQ
DVD	DVD	DVD 2	2	A.POSITION	A. Position	TOP MENU D.MENU	D.Menu / Top
VCR	VCR	VIDEO 4	4	TEST	Test Tone	GOTO TEXT	Text / Goto
TV	TV	TV 1	1	EFFECT	Effect	ANGLE INFO	Info / Angle
FM/AM	FM/AM	TUNER 6	6	DECODE	Decode	PROGRAM TV/RADIO	TV/Radio /
TV/VIDEO	Tv/Video	TAPE 5	5	SURROUND	Surround	SURROUND	Eject / Surround
MUTING	Muting	DIMMER MUTE	Mute / Dimmer	SUBWFR +	Subwfr+		Right
CHANNEL +	Channel +	CH PAGE +	CH+ / Page+	CENTER +	Center+		Up
VOLUME +	Volume+	VOL +	Vol +	L-SUR +	Surr L+	SHIFT + VOL +	Shift + Vol +
	Channel -	CH PAGE −	CH- / Page-	R-SUR +	Surr R+	SHIFT + CH PAGE +	Shift + CH+ /
	Volume-	VOL −	Vol -	SUBWFR −	Subwfr-		Left
ON SCREEN DISPLAY	Display/On Screen	MEDIA DISPLAY	Display / Media	CENTER −	Center-		Down

Original	Replacement	Original	Replacement
Surr L-	SHIFT + VOL − Shift + Vol -		
Surr R-	SHIFT + CH PAGE − Shift + CH- /		

Original		Replacement	
Power Audio		Power	
Power Tv		Shift +	Power
FM/AM		Eject / Surround	
Tv Vol +		Vol +	
Channel + TV		CH+ / Page+	
Tv Vol -		Vol -	
Channel - TV		CH- / Page-	
Tuning- FM/AM		<< / Tune-	
FM Mode FM/AM		Smart / List	
Tuning+ FM/AM		>> / Tune+	
Memory FM/AM		Menu / Home	
TA/News/Info		Info / Angle	
TA/News/Info		Up	
PTY- FM/AM		Left	
PTY+ FM/AM		Right	
PTY Search		Down	
PTY Search		Red / Netflix / Search	

Original		Replacement		
Display FM/AM		Display / Media		
1 FM/AM		Shift +	1	
1 TV		1		
2 FM/AM		Shift +	2	
2 TV		2		
3 FM/AM		Shift +	3	
3 TV		3		
4 FM/AM		Shift +	4	
4 TV		4		
5 FM/AM		Shift +	5	
5 TV		5		
6 FM/AM		Shift +	6	
6 TV		6		
7 FM/AM		Shift +	7	
7 TV		7		
8 FM/AM		Shift +	8	
8 TV		8		

Original		Replacement		Original	Replacement
9	9 FM/AM	SHIFT + BLUETOOTH 9	Shift + 9		
9	9 TV	BLUETOOTH 9	9		
TV RETURN 10	10 FM/AM	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC		
TV RETURN 10	10/Tv Return TV	SHIFT + HDMI - SAT 0	Shift + 0		
0	0 TV	HDMI - SAT 0	0		
100+ +10	+10/100+	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--		
100+ +10	+10 TV	PC FAV MARKER	Fav / Marker / PC		

Original		Replacement	
Power DVD		Power	
I<<		I<< / Preset-	
Play		Play / Slow	
>>I		>>I / Preset+	
<<		<< / Tune-	
Stop		Stop / Hold	
Pause		Pause / Step / Freeze	
Top Menu		D.Menu / Top	
>>		>> / Tune+	
Up		Up	
Menu		Menu / Home	
Left		SHIFT +	Shift + Left
Enter		OK	
Right		Right	
Set Up		Setup / OPT /	
Down		Down	
On Screen		SHIFT +	Shift + Display / Media

Original		Replacement	
Audio		Audio / Lang I/II	
Subtitle		Subtitle / EQ	
Title Group		SHIFT +	Shift + Sound / Title
Return		Back / Return	
DVD Zoom		Zoom / Size	
1		1	
2		2	
3		3	
VFP Progressive		Smart / List	
4		4	
5		5	
6		6	
←		Left	
7		7	
8		8	
9		9	
Angle		Info / Angle	

Original		Replacement		Original	Replacement
TV RETURN 10	10	GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
100+ +10	+10	PC FAV MARKER	Fav / Marker / PC		
DIMMER	Display/Dimmer	MEDIA DISPLAY	Display / Media		
ANALOG/DIGITAL INPUT	Input Analog/Digital	RDS AV INPUT	AV / Input / RDS		
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
EFFECT	HDD Sound Effect	TITLE SOUND	Sound / Title		
SURROUND	Surround	SURROUND	Eject / Surround		

Original		Replacement	
Power VCR		SHIFT +	Shift + Power
Power STB			Power
VCR		SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
Muting		DIMMER MUTE	Mute / Dimmer
Channel +		CH PAGE +	CH+ / Page+
Volume+		VOL +	Vol +
Channel -		CH PAGE −	CH- / Page-
Volume-		VOL −	Vol -
Play VCR		SLOW ▶	Play / Slow
<< VCR		TUNE- ◀◀	<< / Tune-
Stop/Memory		HOLD ■	Stop / Hold
Pause VCR		STEP-FREEZE ⏸	Pause / Step / Freeze
>> VCR		TUNE+ ▶▶	>> / Tune+
1 VCR		SHIFT + TV 1	Shift + 1
1 STB		TV 1	1
2 VCR		SHIFT + DVD 2	Shift + 2
2 STB		DVD 2	2

Original		Replacement	
3 VCR		SHIFT + CD-STB 3	Shift + 3
3 STB		CD-STB 3	3
4 VCR		SHIFT + VIDEO 4	Shift + 4
4 STB		VIDEO 4	4
5 VCR		SHIFT + TAPE 5	Shift + 5
5 STB		TAPE 5	5
6 VCR		SHIFT + TUNER 6	Shift + 6
6 STB		TUNER 6	6
7 VCR		SHIFT + AUX-HDD 7	Shift + 7
7 STB		AUX-HDD 7	7
8 VCR		SHIFT + USB 8	Shift + 8
8 STB		USB 8	8
9 VCR		SHIFT + BLUETOOTH 9	Shift + 9
9 STB		BLUETOOTH 9	9
TV RETURN 10	+10 TV	-/-- GUIDE EPG	Guide / EPG / -/--
0 VCR		SHIFT + HDMI-SAT 0	Shift + 0
0 STB		HDMI-SAT 0	0