Original		Replacement	
	Power		Power
TV/RAD	Tv/Radio	SEARCH TV/R	TV/R
SUBTITLE Q.MENU	Q.Menu/Subtitle	E-MANUAL D.MENU	D. Menu
GUIDE	Guide	GUIDE	Guide
AD	AD	AD SUBT	Subt
INPUT	Input	TIMER AV	AV
1	1	1	1
2 abc	2	2	2
3 def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6 mno	6	6	6
7 pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
LIST	List	DISC NAV LIST	List

Original		Replacement	
Q.VIEW	Q.View	PICTURE FORMAT	Format
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
P PAGE	PR+	+ CH	Ch +
P PAGE	PR-	CH −	Ch -
FAV	Fav	FAV PRE-CH	Pre Ch
INFO	Info	DISPLAY INFO	Info
MUTE	Mute	MUTE	Mute
SMART	Smart	HOME SMART	Smart
MY APPS	My Apps	APP MEDIA	Media
SETTINGS	Settings	SHIFT + SETTINGS OPT	Shift + Options
TEXT	Text	REPEAT TEXT	Text
T.OPT	T.Opt	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
OK	OK	OK	Ok
	Up		Up

Original		Replacement	
	Down		Down
	Right		Right
	Left		Left
APP/*	APP/*	SHIFT + APP MEDIA	Shift + Media
REC/*	Rec/*	REC MODE	Rec
LIVE TV	Stop/Live Tv		Stop
	<<		<<
	>>		>>
	Play	PLAY MODE	Play
	Pause		Pause
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue

Original	Replacement