Original		Replacement	
	Power		Power
	Open/Close		Eject / Surround
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
CLEAR	Clear	EXIT	Exit / Cancel / Clear
0	0	0	0
REPEAT	Repeat	SHIFT + APP	Shift + Green / APP /
	I<<	PRESET-	I<< / Preset-
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+

Original		Replacement	
	>>I	PRESET+	>>I / Preset+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
HOME	Home	HOME MENU	Menu / Home
TITLE/POPUP	Title/PopUp	TITLE SOUND	Sound / Title
TITLE/POPUP	Title/PopUp	LIST SMART	Smart / List
INFO/MENU	Menu/Info	ANGLE INFO	Info / Angle
	Up		Up
	Right		Right
	Left		Left
ENTER	Enter	OK	OK
	Down		Down
BACK	Back	RETURN BACK	Back / Return
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
DISC MENU	Menu Disc	TOP MENU D.MENU	D.Menu / Top
R	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
G Green	APP REPEAT Green / APP / Repeat		
Y Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
B Blue	Prime Video RANDOM Blue / Prime Video / Random		
Power Tv	SHIFT + Power Shift + Power		
MUSIC ID Music ID	MEDIA DISPLAY Display / Media		
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II		
AV/INPUT AV Input Tv	RDS AV INPUT AV / Input / RDS		
VOL+ Vol + Tv	VOL + Vol +		
PR/CH^ PR/CH+ Tv	CH PAGE − CH- / Page-		
MUTE Mute Tv	DIMMER MUTE Mute / Dimmer		
VOL− Vol - Tv	VOL − Vol -		
PR/CH~ PR/CH- Tv	CH PAGE + CH+ / Page+		