Original	Replacement	Original	Replacement
POWER Power	Power	SLEEP Sleep	TIMER SLEEP Sleep / Timer
CBL/SAT CBL/SAT	SHIFT + HDMI-SAT 0 Shift + 0	VOLUME Volume+	+ VOL Vol +
DVD DVD	SHIFT + DVD 2 Shift + 2	CH/Page-	CH PAGE – CH- / Page-
TV AUDIO Tv Audio	SHIFT + TV 1 Shift + 1	MUTE Mute	DIMMER MUTE Mute / Dimmer
Blu-ray Blu-ray	SHIFT + VIDEO 4 Shift + 4	ECO Eco	TOP MENU D.MENU D. Menu / Top
AUX1 AUX1	SHIFT + TAPE 5 Shift + 5	Volume-	VOL – Vol -
TUNER Tuner	SHIFT + TUNER 6 Shift + 6	INFO Info	ANGLE INFO Info / Angle
Bluetooth Bluetooth	SHIFT + BLUETOOTH 9 Shift + 9	Up	Up
AUX2 AUX2	SHIFT + AUX-HDD 7 Shift + 7	OPTION Option	SHIFT + OPT-TOOLS SETUP Shift + Setup / OPT / Tools
GAME Game	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--	Left	Left
PHONO Phono	-/-- GUIDE EPG Guide / EPG / -/--	ENTER Enter	OK OK
USB USB	SHIFT + USB 8 Shift + 8	Right	Right
MEDIA PLAYER Media Player	MEDIA DISPLAY Display / Media	BACK Back	RETURN BACK Back / Return
CD CD	SHIFT + CD-STB 3 Shift + 3	Down	Down
Heos	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC	SETUP Setup	OPT-TOOLS SETUP Setup / OPT /
INTERNET RADIO Internet Radio	LIST SMART Smart / List	HOME Home	HOME MENU Menu / Home
CH/PAGE CH/Page+	+ CH PAGE CH+ / Page+	Stop	HOLD Stop / Hold

Original		Replacement	
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
TUNE	I<<<Tune-	PRESET-	I<< / Preset-
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
1	Smart Select 1	TITLE SOUND	Sound / Title
2	Smart Select 2	LANG I/II AUDIO	Audio / Lang I/II
3	Smart Select 3	EQ SUBTITLE	Subtitle / EQ
4	Smart Select 4	SURROUND	Eject / Surround
MOVIE	Green/Movie	APP REPEAT	Green / APP / Repeat
MUSIC	Red/Music	NETFLIX SEARCH	Red / Netflix / Search
GAME	Blue/Game	Prime Video RANDOM	Blue / Prime Video / Random
PURE	Yellow/Pure	YouTube REPEAT A-B	Yellow / YouTube / Repeat
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Replacement	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
ENTER	Enter	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	Tv Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
Bluetooth	Bluetooth	SHIFT + BLUETOOTH 9	Shift + 9
GAME	Game	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
AUX2	AUX2	SHIFT + AUX - HDD 7	Shift + 7
PHONO	Phono	-/-- GUIDE EPG	Guide / EPG / -/--
USB	USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media
CD	CD	SHIFT + CD - STB 3	Shift + 3
	.:l:.	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
INTERNET RADIO	Internet Radio	LIST SMART	Smart / List
CH / PAGE	CH/Page+	+ CH PAGE	CH+ / Page+

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
VOLUME	Volume+	+ VOL	Vol +
	CH/Page-	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Volume-	VOL −	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
HOME	Home	HOME MENU	Menu / Home
	Stop	HOLD	Stop / Hold
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
+ TUNE	I<</Tune-	PRESET-	I<< / Preset-
TUNE +	>>I/Tune+	PRESET+	>>I / Preset+

Original		Replacement		Original	Replacement
	<<	TUNE- <<	<< / Tune-		
	>>	TUNE+ >>	>> / Tune+		
1	Smart Select 1	TITLE SOUND	Sound / Title		
2	Smart Select 2	LANG I/II AUDIO	Audio / Lang I/II		
3	Smart Select 3	EQ SUBTITLE	Subtitle / EQ		
4	Smart Select 4	SURROUND ⏏	Eject / Surround		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
ENTER	Enter	PC FAV MARKER	Fav / Marker / PC		

Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	Tv Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
Bluetooth	Bluetooth	SHIFT + BLUETOOTH 9	Shift + 9
GAME	Game	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
AUX2	AUX2	SHIFT + AUX - HDD 7	Shift + 7
PHONO	Phono	-/-- GUIDE EPG	Guide / EPG / -/--
USB	USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media
CD	CD	SHIFT + CD - STB 3	Shift + 3
	.:I:.	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
INTERNET RADIO	Internet Radio	LIST SMART	Smart / List
CH / PAGE	CH/Page+	CH PAGE +	CH+ / Page+

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
VOLUME	Volume+	VOL +	Vol +
	CH/Page-	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Volume-	VOL −	Vol -
	Up		Up
	Left		Left
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
HOME	Home	HOME MENU	Menu / Home
	Stop	HOLD	Stop / Hold
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
+/- TUNE	I<<</Tune-	PRESET-	I<< / Preset-
TUNE +	>>I/Tune+	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-

Original		Replacement		Original	Replacement
▸▸	>>	TUNE+ ▸▸	>> / Tune+		
1	Smart Select 1	TITLE SOUND	Sound / Title		
2	Smart Select 2	LANG I/II AUDIO	Audio / Lang I/II		
3	Smart Select 3	EQ SUBTITLE	Subtitle / EQ		
4	Smart Select 4	SURROUND ⏏	Eject / Surround		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
ENTER	Enter	OK	OK		
ENTER	Enter	PC FAV MARKER	Fav / Marker / PC		