Original	Replacement	Original	Replacement
On/Standby	Power	Up	Up
Display	Display / Media	Left	Left
DVD / BD	Shift + 2	Enter	OK
VCR / DVR	Shift + 4	Right	Right
CBL/SAT	Shift + 0	Setup	Setup / OPT /
Game	Shift + 9	Down	Down
AUX	Shift + 7	Return	Back / Return
TV / TAPE	Shift + 5	Audio	Audio / Lang I/II
TV / TAPE	Shift + 1	I <<	I << / Preset-
TUNER	Shift + 6	>>I	>>I / Preset+
PORT	Shift + 8	<<	<< / Tune-
CD	Shift + 3	Play	Play / Slow
Muting	Mute / Dimmer	>>	>> / Tune+
CH/Disc/Album	CH+ / Page+	Pause	Pause / Step / Freeze
Vol +	Vol +	Stop	Stop / Hold
CH/Disc/Album-	CH- / Page-	Movie Tv	Red / Netflix / Search
Vol -	Vol -	Music	Green / APP / Repeat

Original		Replacement		Original	Replacement
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
STEREO PLAY MODE	Stereo	Prime Video RANDOM	Blue / Prime Video / Random		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10 D.TUN DIMMER	+10/ - - / - - - 10/ Dimer / D. Tun	-/-- GUIDE EPG	Guide / EPG / - / - -		
0	0/ 11	HDMI - SAT 0	0		
CLR SLEEP	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC		
CLR SLEEP	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer		
CLR SLEEP	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

Original		Replacement	
	Power BD/DVD		Power
	DVD/BD		Smart / List
	CBL/SAT		Display / Media
	Vol + Receiver		Vol +
	Vol - Receiver		Vol -
	Top Menu		D.Menu / Top
	Up BD/DVD		Up
	Menu BD/DVD		Menu / Home
	Left BD/DVD		Left
	Enter BD/DVD		OK
	Right BD/DVD		Right
	Setup BD/DVD		Setup / OPT /
	Down BD/DVD		Down
	Return BD/DVD		Back / Return
	Audio BD/DVD		Audio / Lang I/II
	I<< BD/DVD		I<< / Preset-
	>>I BD/DVD		>>I / Preset+

Original		Replacement	
	<< BD/DVD		<< / Tune-
	Play BD/DVD		Play / Slow
	>> BD/DVD		>> / Tune+
	Pause BD/DVD		Pause / Step / Freeze
	Stop BD/DVD		Stop / Hold
	Search BD/DVD		Red / Netflix / Search
	Repeat BD/DVD		Green / APP / Repeat
	Random		Blue / Prime Video / Random
	Play Mode		Yellow / YouTube / Repeat
	1 BD/DVD		1
	2 BD/DVD		2
	3 BD/DVD		3
	4 BD/DVD		4
	5 BD/DVD		5
	6 BD/DVD		6
	7 BD/DVD		7
	8 BD/DVD		8

Original		Replacement	
9	9 BD/DVD	BLUETOOTH 9	9
+10 DIMMER	+10/--/--10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0/11 BD/DVD	HDMI - SAT 0	0
CLR SLEEP	CLR/12 BD/DVD	PC FAV MARKER	Fav / Marker / PC
CLR SLEEP	CLR/12 BD/DVD	CLEAR EXIT CANCEL	Exit / Cancel / Clear
ON/STANDBY	Power CBL/SAT	SHIFT +	Shift + Power
CH DISC	CH Disc/Album+ CBL/SAT	SHIFT + CH PAGE +	Shift + CH+ /
ALBUM	CH Disc/Album- CBL/SAT	SHIFT + CH PAGE -	Shift + CH- /
GUIDE/TOP MENU	Guide CBL/SAT	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
	Up CBL/SAT	SHIFT +	Shift + Up
PREV CH/MENU VIDEO	Menu/Prev CH CBL/SAT	SHIFT + HOME MENU	Shift + Menu /
PLAYLIST /CATEGORY	Left CBL/SAT	SHIFT +	Shift + Left
ENTER	Enter CBL/SAT	SHIFT + OK	Shift + OK
PLAYLIST /CATEGORY	Right CBL/SAT	SHIFT +	Shift + Right
SETUP	Setup CBL/SAT	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Down CBL/SAT	SHIFT +	Shift + Down
RETURN	Return CBL/SAT	SHIFT + RETURN BACK	Shift + Back / Return

Original		Replacement	
<<	<< CBL/SAT	SHIFT + TUNE-	Shift + << /
►	Play CBL/SAT	SHIFT + SLOW ▶	Shift + Play /
>>	>> CBL/SAT	SHIFT + TUNE+	Shift + >> /
❚❚	Pause CBL/SAT	SHIFT + STEP - FREEZE ❚❚	Shift + Pause / Step /
■	Stop CBL/SAT	SHIFT + HOLD ■	Shift + Stop /
MOVIE/TV SEARCH	Movie Tv/Search CBL/SAT	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
MUSIC REPEAT	Music/Repeat CBL/SAT	SHIFT + APP REPEAT	Shift + Green / APP /
GAME RANDOM	Game/Random	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
STEREO PLAY MODE	Stereo/Play Mode CBL/SAT	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
1	1 CBL/SAT	SHIFT + TV 1	Shift + 1
2	2 CBL/SAT	SHIFT + DVD 2	Shift + 2
3	3 CBL/SAT	SHIFT + CD - STB 3	Shift + 3
4	4 CBL/SAT	SHIFT + VIDEO 4	Shift + 4
5	5 CBL/SAT	SHIFT + TAPE 5	Shift + 5
6	6 CBL/SAT	SHIFT + TUNER 6	Shift + 6
7	7 CBL/SAT	SHIFT + AUX - HDD 7	Shift + 7
8	8 CBL/SAT	SHIFT + USB 8	Shift + 8

Original	Replacement	Original	Replacement
9 CBL/ SAT	SHIFT + BLUETOOTH 9 Shift + 9		
0/ 11 CBL/ SAT	SHIFT + HDMI - SAT 0 Shift + 0		

Original		Replacement	
ON/STANDBY	Power CD		Power
CD	CD	LIST SMART	Smart / List
CH DISC	CH/Disc+ CD	CH PAGE	CH+ / Page+
VOL	Vol + Receiver	VOL	Vol +
ALBUM	CH/Disc- CD	CH PAGE	CH- / Page-
VOL	Vol - Receiver	VOL	Vol -
	Up CD		Up
PLAYLIST /CATEGORY	Left CD		Left
ENTER	Enter CD	OK	OK
PLAYLIST /CATEGORY	Right CD		Right
SETUP	Setup CD	OPT-TOOLS SETUP	Setup / OPT /
	Down CD		Down
RETURN	Return CD	RETURN BACK	Back / Return
AUDIO	Audio CD	LANG I/II AUDIO	Audio / Lang I/II
	I<< CD	PRESET-	I<< / Preset-
	>>I CD	PRESET+	>>I / Preset+
	<< CD	TUNE-	<< / Tune-

Original		Replacement	
	Play CD	SLOW	Play / Slow
	>> CD	TUNE+	>> / Tune+
	Pause CD	STEP-FREEZE	Pause / Step / Freeze
	Stop CD	HOLD	Stop / Hold
MOVIE/TV SEARCH	Search CD	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Repeat CD	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Random CD	Prime Video RANDOM	Blue / Prime Video / Random
STEREO PLAY MODE	Play Mode CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
1	1 CD	TV 1	1
2	2 CD	DVD 2	2
3	3 CD	CD-STB 3	3
4	4 CD	VIDEO 4	4
5	5 CD	TAPE 5	5
6	6 CD	TUNER 6	6
7	7 CD	AUX-HDD 7	7
8	8 CD	USB 8	8
9	9 CD	BLUETOOTH 9	9

Original	Replacement	Original	Replacement
+10/ - - / - - 10/ D. Tu Dimmer CD	Guide / EPG / - / - -		
0/ 11 CD	0		
CLR/ Sleep/ 12	Fav / Marker / PC		

Original		Replacement	
ON/STANDBY	Power Receiver Zone 2		Power
CH DISC	CH Disc/Album+ Zone 2	CH PAGE	CH+ / Page+
VOL	Vol + Zone 2	VOL	Vol +
ALBUM	CH Disc/Album- Zone 2	CH PAGE	CH- / Page-
VOL	Vol - Zone 2	VOL	Vol -
	Up Zone 2		Up
PLAYLIST /CATEGORY	Left Zone 2		Left
ENTER	Enter Zone 2	OK	OK
PLAYLIST /CATEGORY	Right Zone 2		Right
SETUP	Setup Zone 2	OPT-TOOLS SETUP	Setup / OPT /
	Down Zone 2		Down
RETURN	Return Zone 2	RETURN BACK	Back / Return
AUDIO	Audio Zone 2	LANG I/II AUDIO	Audio / Lang I/II
	I << Zone 2	PRESET-	I << / Preset-
	>>I Zone 2	PRESET+	>>I / Preset+
	<< Zone 2	TUNE-	<< / Tune-
	Play Zone 2	SLOW	Play / Slow

Original		Replacement	
	>> Zone 2	TUNE+	>> / Tune+
	Pause Zone 2	STEP-FREEZE	Pause / Step / Freeze
	Stop Zone 2	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie Tv Zone	NETFLIX SEARCH	Red / Netflix / Search
LISTENING MUSIC REPEAT	Music Zone 2	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Game Zone 2	YouTube REPEAT A-B	Yellow / YouTube / Repeat
STEREO PLAY MODE	Stereo Zone 2	Prime Video RANDOM	Blue / Prime Video / Random
1	1 Zone 2	TV 1	1
2	2 Zone 2	DVD 2	2
3	3 Zone 2	CD-STB 3	3
4	4 Zone 2	VIDEO 4	4
5	5 Zone 2	TAPE 5	5
6	6 Zone 2	TUNER 6	6
7	7 Zone 2	AUX-HDD 7	7
8	8 Zone 2	USB 8	8
9	9 Zone 2	BLUETOOTH 9	9
+10 DIMMER	+10/--/--10/D.Tu Dimmer Zone 2	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Replacement	Original	Replacement
0/ 11 Zone 2	0		
CLR/ Sleep/ 12	Fav / Marker / PC		