Original		Replacement	
	Power		Power
	Up / P+		Up
	Up / P+		CH+ / Page+
	Menu		Menu / Home
	Left		Left
	Right		Right
	Down / P-		Down
	Down / P-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9

Original		Replacement	
	- -		Guide / EPG / -/--
	0		0
	P < P		Fav / Marker / PC
	PP		Back / Return
	Vol +		Vol +
	I-II		Audio / Lang I/II
	Mute		Mute / Dimmer
	Vol -		Vol -
	Info		Info / Angle
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	[TV]		Shift + 1
	[TV]		TV/Radio /
	[AV]		AV / Input / RDS
	[≡]		Text / Goto

Original		Replacement		Original	Replacement
TIME	[≡◷]	EQ SUBTITLE	Subtitle / EQ		
	[/ ≡]	FORMAT PICTURE	Picture / Format		
	[≡X]	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	[≡↕]	SIZE ZOOM	Zoom / Size		
TITLE LANG.	[≡?]	MEDIA DISPLAY	Display / Media		
OPEN/CLOSE TV/RADIO	[≡i]	LIST SMART	Smart / List		

Original		Replacement	
	Power		Power
	Up / P+		Up
	Up / P+		CH+ / Page+
	Menu		Menu / Home
	Left		Left
	Select		OK
	Right		Right
	Down / P-		CH- / Page-
	Down / P-		Down
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8

Original		Replacement	
	9		9
	+10		Guide / EPG / -/--
	0		0
	Repeat		Green / APP / Repeat
	Search		Red / Netflix / Search
	A→B		Yellow / YouTube / Repeat
	Display		Display / Media
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Zoom		Zoom / Size
	Prog		TV/Radio /
	C		Blue / Prime Video / Random
	Angle		Info / Angle
	Return		Back / Return
	Time		Sleep / Timer
	◀◀		<< / Tune-
	▶▶		>> / Tune+

Original		Replacement		Original	Replacement
	⏮	PRESET- ⏮	I << / Preset-		
	⏭	PRESET+ ⏭	>>I / Preset+		
	▶/❚❚	SLOW ▶	Play / Slow		
	▶/❚❚	STEP-FREEZE ❚❚	Pause / Step / Freeze		
	■	HOLD ■	Stop / Hold		
	Title	TITLE SOUND	Sound / Title		
	Open / Close	SURROUND ⏏	Eject / Surround		

Original	Replacement	Original	Replacement
On/Off	Power	Menu Right	Right
Mute	Mute / Dimmer	Menu Down	Down
Txt Stop	Stop / Hold	Back	Back / Return
Tone+	>> / Tune+	Volume+	Vol +
Lang	Sound / Title	Chan. Up	CH+ / Page+
Menu audio	Audio / Lang I/II	Volume-	Vol -
Subt. List	Subtitle / EQ	Display	Display / Media
Txt Expand	Zoom / Size	Chan. Down	CH- / Page-
Sleep Timer	Sleep / Timer	1	1
Return TV	TV/Radio /	2	2
Menu video	D. Menu / Top	3	3
Text	Text / Goto	4	4
Menu	Menu / Home	5	5
Menu Up	Up	6	6
Info	Info / Angle	7	7
Menu Left	Left	8	8
OK Enter	OK	9	9

Original	Replacement	Original	Replacement
Guide -/-- 1.	GUIDE EPG Guide / EPG / -/--		
0/10	HDMI - SAT 0 0		
2. Fav P/C 2.	PC FAV MARKER Fav / Marker / PC		
Red	NETFLIX SEARCH Red / Netflix / Search		
Green	APP REPEAT Green / APP / Repeat		
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM Blue / Prime Video / Random		
Lang	SHIFT + LANG I/II AUDIO Shift + Audio / Lang I/II		