Original		Replacement	
	Power		Power
	SD/HC	MEDIA DISPLAY	Display / Media
INPUT TV	Input TV	SHIFT + TV 1	Shift + 1
INPUT TV	Input TV	PROGRAM TV/ RADIO	TV/Radio /
INPUT AV	Input AV	RDS AV INPUT	AV / Input / RDS
ASPECT	[+]/Aspect	FORMAT PICTURE	Picture / Format
MENU	Menu	HOME MENU	Menu / Home
N	N	LANG I/II AUDIO	Audio / Lang I/II
DIRECT TV REC	Direct Tv Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode
	i	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VIERA TOOLS	Viera Tools	TOP MENU D.MENU	D.Menu / Top
VIERA Link	Viera Link	LIST SMART	Smart / List
	Up		Up
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Left		Left
OK	OK	OK	OK

Original		Replacement	
	Right		Right
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
BACK/ RETURN	Back/Return	RETURN BACK	Back / Return
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
TEXT	Text	GOTO TEXT	Text / Goto
STTL	STTL	EQ SUBTITLE	Subtitle / EQ
INDEX	Index	SIZE ZOOM	Zoom / Size
HOLD	Hold	SHIFT + HOLD	Shift + Stop /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5

Original		Replacement	
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	Mute	DIMMER MUTE	Mute / Dimmer
0	0	HDMI - SAT 0	0
	(<>)	TITLE SOUND	Sound / Title
+	Vol +	+ VOL	Vol +
^	CH+	+ CH PAGE	CH+ / Page+
–	Vol -	VOL –	Vol -
v	CH-	CH PAGE –	CH- / Page-
	Power Down	SHIFT +	Shift + Power
REC	Rec	REC MODE	Rec / Rec Mode
PROGR v	Programme	SHIFT + CH PAGE –	Shift + CH- /
RAMME ^	Programme Up	SHIFT + + CH PAGE	Shift + CH+ /
<<	<<	TUNE- <<	<< / Tune-
I <<	I <<	PRESET- I <<	I << / Preset-

Original		Replacement	
▶	Play	SLOW ▶	Play / Slow
▶▶I	>>	TUNE+ ▶▶	>> / Tune+
▶▶I	>>I	PRESET+ ▶▶I	>>I / Preset+
■	Stop	HOLD ■	Stop / Hold
DVD II/I▶	Pause/Step	STEP - FREEZE II	Pause / Step / Freeze

Original	Replacement
Power Down	Power
Rec	Rec / Rec Mode
Programme	CH- / Page-
Programme Up	CH+ / Page+
<<	<< / Tune-
I <<	I << / Preset-
Play	Play / Slow
>>	>> / Tune+
>>I	>>I / Preset+
Stop	Stop / Hold
Pause/Step	Pause / Step / Freeze

Original	Replacement