Original		Replacement		Original		Replacement	
	Power		Power		[≡♦] / F. P.		Zoom / Size
	Mute		Mute / Dimmer		[≡i] / Index		Shift + Play /
	Direct Tv Rec		Smart / List		[≡+] / Hold		Shift + Stop /
	Guide		Guide / EPG / -/--	1	1		1
	Up		Up	2	2		2
	Tv/AV		AV / Input / RDS	3	3		3
	Left		Left	4	4		4
	OK		OK	5	5		5
	Right		Right	6	6		6
	Menu		Menu / Home	7	7		7
	Down		Down	8	8		8
	Exit		Exit / Cancel / Clear	9	9		9
	Red		Red / Netflix / Search	C	C		D. Menu / Top
	Green		Green / APP / Repeat	0 VCR	0/ VCR		0
	Yellow		Yellow / YouTube / Repeat		i		Info / Angle
	Blue		Blue / Prime Video / Random		CH+		CH+ / Page+
	[≡] / Text		Text / Goto		Vol +		Vol +

Original	Replacement	Original	Replacement
CH-	CH- / Page-		
Vol -	Vol -		
[+] / Aspect	Picture / Format		
N	Setup / OPT /		
Power VCR	Shift + Power		
Rec VCR	Rec / Rec Mode		
Programme Down	Shift + CH- /		
Programme Up	Shift + CH+ /		
<< VCR	<< / Tune-		
>> VCR	>> / Tune+		
Stop VCR	Stop / Hold		
Pause/Step VCR	Pause / Step / Freeze		
Play VCR	Play / Slow		

Original		Replacement		Original		Replacement	
	Power DVD		Power				
	Rec DVD		Rec / Rec Mode				
	Programme Down		CH- / Page-				
	Programme Up		CH+ / Page+				
	I<< DVD		I<< / Preset-				
	>>I DVD		>>I / Preset+				
	Stop DVD		Stop / Hold				
	Pause/Step DVD		Pause / Step / Freeze				
	Play DVD		Play / Slow				