| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| DRIVE SELECT | Select Drive | HOME SMART | Smart |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| INPUT SELECT | Input Select | APP MEDIA | Media |
| CH | CH+/ Tracking/V-Lock | CH + | Ch + |
| CH | CH-/ Tracking/V-Lock/ | CH − | Ch - |
| ShowView | ShowView | FAV PRE-CH | Pre Ch |
| PAUSE | Pause | | Pause |

| Original | | Replacement | |
|---|---|---|---|
| PLAY | Play | PLAY MODE | Play |
| STOP | Stop | | Stop |
| SEARCH FF | >> | | >> |
| SLOW/SEARCH REW | << | | << |
| INDEX | >>I | | >>I |
| SKIP | I << | | I << |
| STATUS | i/Status | DISPLAY INFO | Info |
| RETURN | Return | RETURN BACK | Back |
| EXIT | Exit | CLEAR EXIT | Exit |
| FUNCTION MENU | Function Menu | TOP MENU MENU | Menu |
| PROG/CHECK | Prog/Check | SEARCH TV/R | TV/R |
| OPTION | Option | SETTINGS OPT | Options |
| DELETE RESET | Delete/Reset | SHIFT + CLEAR EXIT | Shift + Exit |
| GUIDE | Guide | -/-- GUIDE | Guide |
| DIRECT NAVIGATOR | Direct Navigator | E-MANUAL D.MENU | D. Menu |
| OK | OK | OK | Ok |
| | Up | | Up |

| Original | | Replacement | |
|---|---|---|---|
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| | Red | A | Red |
| CHAPTER | Green/Chapter | B | Green |
| MANUAL SKIP -10s | Yellow/Manual Skip -10S | C | Yellow |
| SKIP +60s | Blue//Manual Ski +60S | D | Blue |
| REC | Rec | REC MODE | Rec |
| DIRECT TV REC | Direct Tv Rec | SHIFT + SEARCH TV/R | Shift + TV/R |
| REC MODE | Rec Mode | SHIFT + REC MODE | Shift + Rec |
| EXT LINK | Ext Link | REPEAT TEXT | Text |
| AUDIO | Audio | SOUND DUAL | Dual |
| DISPLAY | Display | SHIFT + DISPLAY INFO | Shift + Info |
| STTL | [≡♦]/STTL | AD SUBT | Subt |
| TIME SLIP JET REW | Time Slip/<<Jet | PROG SLEEP | Sleep |
| TIME SLIP JET REW | Time Slip/<<Jet | SHIFT + << | Shift + << |
| TV | Tv Power | SHIFT + | Shift + Power |

| Original | | Replacement | |
|---|---|---|---|
| AV | AV Tv | TIMER AV | AV |
| VOL + | Vol + Tv | VOL + | Vol + |
| VOL - | Vol - Tv | VOL - | Vol - |
| CH ∧ | CH+ Tv | SHIFT + CH + | Shift + Ch + |
| CH ∨ | CH- Tv | SHIFT + CH - | Shift + Ch - |