Original		Replacement	
	Power		Power
ENR DIRECT	Enr Direct	SHIFT + REC MODE	Shift + Rec / Rec Mode
FORMAT	Format	FORMAT PICTURE	Picture / Format
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
ALIGN/STAB.VERT.	Align / Stab. Vert. +	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	Align / Stab. Ver	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+	Vol +	+ VOL	Vol +
SELECT ENT AV	AV / Select En	RDS AV INPUT	AV / Input / RDS

Original		Replacement	
0	0	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
−	Vol -	VOL −	Vol -
RECHERCHE	Recherche	NETFLIX SEARCH	Red / Netflix / Search
INDEX	I<< Index	PRESET-	I<< / Preset-
INDEX	Index >>I	PRESET+	>>I / Preset+
SHOW VIEW	ShowView	ANGLE INFO	Info / Angle
MODE PHOTO	Mode Photo	LIST SMART	Smart / List
RELECTURE	Relecture	RETURN BACK	Back / Return
	Pause/Step	STEP-FREEZE	Pause / Step / Freeze
ENR	Enr	REC MODE	Rec / Rec Mode
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Play	SLOW	Play / Slow
SORTIE	Sortie	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
	<<	TUNE-	<< / Tune-

Original	Replacement
OK	OK
Right	Right
>>	>> / Tune+
Down	Down
Stop	Stop / Hold
Verif Up	Shift + Up
Date+	Shift + Right
Deb+	Shift + Vol +
Fin+	Shift + CH+ /
Verif Down	Shift + Down
Date-	Shift + Left
Deb-	Shift + Vol -
Fin-	Shift + CH- /
Verif	TV/Radio /
Annul	Shift + Exit / Cancel / Clear
SP/LP/EP	Setup / OPT /
Prog	Sleep / Timer

Original	Replacement
I-Timer	Shift + Sleep / Timer
Audio	Audio / Lang I/II
OSD/Affich	Display / Media
Reset	Green / APP / Repeat

Original		Replacement	
	Power		Power
ENR DIRECT	Enr Direct	PROGRAM TV/RADIO	TV/Radio /
FORMAT	Format	SIZE ZOOM	Zoom / Size
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
ALIGN/STAB.VERT.	Align/Stab. Vert	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	Align/Stab. Vert	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+	Volume+	+ VOL	Vol +
SELECT ENT AV	AV/Select Ent	RDS AV INPUT	AV / Input / RDS

Original		Replacement	
0	0	HDMI-SAT 0	0
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
−	Volume-	VOL −	Vol -
RECHERCHE	Recherche	NETFLIX SEARCH	Red / Netflix / Search
INDEX	I<< Index	PRESET-	I<< / Preset-
INDEX	Index >>I	PRESET+	>>I / Preset+
SHOW VIEW	Show View	FORMAT PICTURE	Picture / Format
MODE PHOTO	Mode Photo	OPT-TOOLS SETUP	Setup / OPT /
RELECTURE	Relecture	MEDIA DISPLAY	Display / Media
II/▶	Pause/Step	STEP-FREEZE II	Pause / Step / Freeze
ENR	Enr	REC MODE	Rec / Rec Mode
MENU	Menu	HOME MENU	Menu / Home
▶	Play	SLOW ▶	Play / Slow
▲	Up	▲	Up
SORTIE	Sortie	CLEAR EXIT CANCEL	Exit / Cancel / Clear
◀◀	<<	TUNE- ◀◀	<< / Tune-
◀	Left	◀	Left

Original	Replacement
OK	OK
Right	Right
>>	>> / Tune+
Down	Down
Stop	Stop / Hold
Verif Up/Red	Shift + CH+ /
Date+/Green	Shift + 2
Deb+/Yellow	Shift + 3
Fin+/Blue	Shift + 7
Verif Down	Shift + CH- /
Date-	Shift + 5
Deb-	Shift + 6
Fin-	Guide / EPG / -/--
Verif	Back / Return
Annul	Shift + Exit / Cancel / Clear
SP/LP/EP	Subtitle / EQ
Prog	Sleep / Timer

Original	Replacement
Reset	Shift + 4
Audio	Audio / Lang I/II
OSD Affich	Info / Angle
AV Link	Smart / List

Original		Replacement	
	Power		Power
FORMAT	Format	FORMAT PICTURE	Picture / Format
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
ALIGN/STAB.VERT. +	Align / Stab. Vert. +	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	Align / Stab. Ver	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+	Vol +	+ VOL	Vol +
SELECT.ENT AV	AV/Select Ent	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0

Original		Replacement	
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
−	Vol -	VOL −	Vol -
^	Verif Up	▲	Up
^	Red	NETFLIX SEARCH	Red / Netflix / Search
+ DATE	Green	APP REPEAT	Green / APP / Repeat
+ DATE	Date+	▶	Right
+ DEB	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
+ DEB	Deb+	SHIFT + + VOL	Shift + Vol +
+ FIN	Blue	Prime Video RANDOM	Blue / Prime Video / Random
+ FIN	Fin+	SHIFT + + CH PAGE	Shift + CH+ /
v	Verif Down	▼	Down
DATE −	Date-	◀	Left
DEB −	Deb-	SHIFT + VOL −	Shift + Vol -
FIN −	Fin-	SHIFT + CH PAGE −	Shift + CH- /